

Temperature Setting Guide

Temp. Setting	Hair Type
Low 1–5	Delicate, thin, easy-to-style hair
Med. 6–10	Average to thick or treated hair
Med.- High 11–15	Thick or wavy hair
High 16–20	Hard-to-style hair
Maximum 21–30	Very resistant hair
Turbo Heat®	Up to 20°C/36°F burst of heat for difficult styling spots

WARNING: The barrel will get very hot within a few seconds and should not be placed in contact with the skin after the curling iron is turned on. Always do a test curl before using the curling iron to ensure the proper setting for your hair type.

USER MAINTENANCE

Your styling tool is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the appliance from the power source, allow to cool, and wipe exterior with a cloth. If any abnormal condition occurs, unplug it, allow it to cool and return it for repair to an authorized service center only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power supply cord to be pulled or twisted. Never wrap the cord around the appliance. Damage will occur at the high flex point of entry into the appliance causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your styling tool is easy to store. Allow it to cool, and store out of reach of children in safe, dry location. Do not jerk or strain cord at plug connections.

Do not wrap cord tightly around appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

described in this manual. Do not use attachments not recommended by the manufacturer.

4. Do not use an extension cord to operate appliance.

5. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**

6. **Keep the cord away from heated surfaces.**

7. **Do not pull, twist, or wrap line cord around appliance.**

8. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.

9. Never use while sleeping.

10. Never drop or insert any object into any opening or hose.

11. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

12. This appliance is hot when in use. Do not let heated surfaces touch eyes and bare skin.

13. **Do not place the heated appliance directly on any surface or on the appliance power cord while it is hot or plugged in. Use the built-in counter rest.**


14. Do not use with a voltage converter.

15. Do not touch hot surfaces of the appliance. Use the handles or knobs.

16. Do not attempt to touch the housing of your appliance near the barrel as it is hot when in use.

**WARNING:
IF YOU THINK
THE POWER IS OFF
WHEN THE SWITCH
IS OFF,
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG
SMALL APPLIANCES**

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

**READ ALL INSTRUCTIONS
BEFORE USING**

KEEP AWAY FROM WATER

DANGER — Any appliance is electrically live even when the switch is off.

To reduce the risk of death by electric shock:

1. **Always unplug appliance immediately after using.**

2. Do not use while bathing or in the shower.

3. Do not place or store appliance where it can fall or be pulled into a tub or sink.

4. Do not place in, or drop into water or other liquids.

5. If an appliance falls into water, unplug the appliance immediately. **Do not reach into the water.**

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**

2. This appliance should not be used by, on, or near children or individuals with certain disabilities.

3. Use this appliance only for its intended use as

NOTE: Do not use this styling appliance on hair extensions.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This appliance is intended for household use. Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 120 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

GETTING STARTED

Hair should be clean and completely dry before using the curling iron. Plug the iron into an electrical outlet. Turn on unit. The power indicator light will become illuminated. Allow unit to heat up for 30 seconds.

WARNING: The curling iron's barrel will get very hot within a few seconds and should not be placed in contact with the skin after the curling iron has been turned on.

The appliance's 30 temperature settings and instant heat technology combine to provide styling versatility for all hair textures. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or coarse hair, keep the heat setting high. You can vary the

LIMITED TWO-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt and \$7.50 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

appliance's temperature according to your particular need!

CURLING BASICS

1. Plug the curling iron cord into any household outlet (120 VAC). Press power ON/OFF button (indicator light will blink). The iron will heat up very quickly; when red light stops blinking, the unit is ready to use. To turn off, press power ON/OFF button again. **Never leave your curling iron on and unattended.** However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

2. Section dry hair evenly, and comb each section before winding. Pressing the automatic curl release, position curling iron midway up the hair section, then spread hair evenly between spoon and barrel. Release automatic curl release to hold hair in place. Gently slide curling iron down to hair ends. To avoid crimped ends, make sure they are securely wound under the spoon in the direction of the desired curl.

Remember, always place the spoon above the hair strand when making a curl you want rolled under; place the spoon under the hair strand when making a flip style.

3. Wind the hair up as far as you want it curled, being careful not to let the iron touch the scalp. Hold in place for 8 to 12 seconds, depending on the texture and length of your hair. For tighter, bouncier curls, roll less hair. For looser, free-flowing curls, roll more hair.

4. To remove curling iron, unwind the hair and press the automatic curl release. To set the curl, do not comb or brush hair until it cools.

5. To achieve faster styling results, the unit features a unique, optional Turbo Heat® burst. Press the

Service Center

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

Please register this product at:
www.conair.com/registration

For information on any Conair or Infiniti PRO by Conair product, call 1-800-3-CONAIR or visit us on the web at: www.conair.com/infiniti

©2016 Conair Corporation
150 Milford Road, East Windsor, NJ 08520
7475 N. Glen Harbor Blvd., Glendale, AZ 85307

16PA019337

IB-14233

infinitiPRO CONAIR GOLD

1 in. TOURMALINE CERAMIC CURLING IRON



Instruction & Styling Guide
For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

CONAIR®

Model 2014G

Turbo ON/OFF button to deliver up to 20°C/36°F more heat for maximum styling performance.

TOURMALINE CERAMIC EASY-GLIDE BARREL

The barrel of your new curling iron has a Tourmaline Ceramic Technology easy-glide surface, the newest technology. This means it's not only simpler to clean off styling product residue, etc., after each use, but you'll find that hair glides easily over the surface of the barrel as you're curling. The tourmaline ceramic surface also helps smooth down flyaways and frizzies. It evenly distributes heat so that the style you create has a salon-perfect, silky smooth, shining finish. Hair also slips right through the barrel after it's curled.

The new Tourmaline Ceramic Technology is a pleasure to work with and makes styling your hair easier and the results more professional.



Guía de temperatura

Ajuste de temperatura	Tipo de cabello
Bajo 1–5	Cabello delicado, fino o dócil
Medio 6–10	Cabello normal a grueso o tratado
Medio/Alto 11–15	Cabello grueso u ondulado
Alto 16–20	Cabello resistente
Máximo 21–30	Cabello muy resistente
Botón Turbo Heat®	Aumenta la temperatura en 20 °C (36 °F), para lograr resultados más rápidos en áreas resistentes

ADVERTENCIA: el tubo se pone muy caliente en segundos; evite el contacto con la piel después de encender el aparato. Siempre haga una prueba preliminar para asegurarse de que esté usando el nivel de temperatura adecuado para su cabello.

INSTRUCCIONES DE MANTENIMIENTO

Su aparato requiere poco mantenimiento. No necesita lubricación. Mantenga todas las aberturas libres de polvos y pelusas. Cuando sea necesario limpiarlo, desenchúfelo, permita que se enfríe y limpie la superficie exterior con un paño limpio. En caso de mal funcionamiento, desconecte el aparato, permita que se enfríe y regréselo a un centro de servicio autorizado. No trate de reparar el aparato.

PRECAUCIÓN

NUNCA jale, tuerza ni retuerza el cable eléctrico. Nunca enrolle el cable alrededor del aparato; esto podría dañar la junta flexible que lo conecta al aparato, produciendo su ruptura o un cortocircuito. Revise el cable con frecuencia para asegurarse de que no esté dañado. Deje de usar el aparato inmediatamente si el cable parece dañado o si el aparato dejara de funcionar o funcionara de manera intermitente.

ALMACENAJE

Cuando no lo utiliza, su aparato es fácil de almacenar. Permita que se enfríe y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No tiree ni retuerza el cable al nivel del enchufe.


No enrolle el cable alrededor del aparato. Permita que el cable cuelgue o que la junta que lo conecta al aparato esté suelta y recta.

riesgo de quemaduras, electrocución, incendio o heridas:

1. **Nunca descuide ni abandone el aparato mientras está conectado.**
2. Este aparato no debe ser usado por, sobre cerca de niños o personas con ciertas discapacidades.
3. Utilice este aparato únicamente con el propósito para el cual fue diseñado y solamente según las instrucciones. Solo use accesorios recomendados por el fabricante.
4. No utilice una extensión con este aparat
5. **No utilice este aparato si el cable o la clavija estuviesen dañados, si no funcionan debidamente, si estuviese dañado, o después de que se hubiese caído al piso o al agua; regréselo a un centro de servicio autorizado para su revisión y reparación.**
6. **Mantenga el cable alejado de las superficies calientes.**
7. **No jale, retuerza ni enrolle el cable alrededor del aparato.**
8. Nunca bloquee las aberturas de aire ni coloque el aparato sobre una superficie blanda, tal como una cama o un sofá, donde se puedan obstruir. Mantenga las aberturas libres de pelusas, cabellos y elementos similares.
9. No lo use mientras duerm
10. Nunca deje caer ni inserte ningún objeto ninguna de las aberturas del aparato.
11. No utilice el aparato en exteriores, ni lo h funcionar donde se estén usando productos en aerosol (spray) o donde se esté administrando oxígeno.
12. Este aparato se vuelve muy calien

**ADVERTENCIA:
SI CREE QUE NO HAY
CORRIENTE CUANDO
EL APARATO ESTÁ
APAGADO,
ESTÁ EQUIVOCADO.**

MANTÉNGALO ALEJADO DEL AGUA



Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece bajo tensión aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe los aparatos eléctricos después del uso.

SIEMPRE DESENCHUFE LOS APARATOS PEQUEÑOS

Mantenga los ojos y la piel alejados de las superficies calientes.

13. **No coloque el aparato sobre ninguna superficie mientras está caliente o conectado; utilice el soporte integrado. Manténgalo alejado del cable eléctrico.**

14. No utilice este aparato con un convertidor de voltaje.

15. No toque las partes calientes de este aparato; utilice los mangos/asas o los botones/perillas.

16. El cuerpo del aparato cerca del tubo se vuelve muy caliente durante el uso; no lo toque.

NOTA: no utilice este aparato sobre cabello sintético/extensionses.

GUARDE ESTAS INSTRUCCIONES DE OPERACIÓN

Para uso doméstico solamente. Utilícelo solamente con corriente alterna (60 Hz). Este aparato ha sido diseñado para funcionar con corriente de 120 V AC

El cable de este aparato está dotado de una clavija polarizada (una pata es más ancha que la otra). Como medida de seguridad, se podrá enchufar de una sola manera en la toma de corriente polarizada. Si no entrara en la toma de corriente, invírtala. Si aún no entrara completamente, comuníquese con un electricista. No intente ir en contra de esta función de seguridad.

GARANTÍA LIMITADA DE DOS AÑOS (VÁLIDA EN LOS EE.UU. Y EN CANADÁ SOLAMENTE)

Conair reparará o reemplazará (a su opción) su aparato sin cargo por un período de 24 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regrese su aparato al Centro de Servicio indicado a continuación, junto con su recibo de compra y un cheque o giro postal de US\$7.50 para cubrir los gastos de manejo y envío. Los residentes de California solo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 24 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 24 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O

FUNCIONAMIENTO BÁSICO

El cabello debe estar limpio y seco. Conecte el cable a una toma de corriente. Encienda (“ON”) el aparato; La luz de encendido se encenderá. Permita que la unidad se caliente por 30 segundos.

ADVERTENCIA: el tubo se pone muy caliente en segundos; evite el contacto con la piel después de encender el aparato.

Este aparato ofrece 30 opciones de temperatura, para todo tipo de cabello, y calienta muy rápidamente. Si su cabello es fino, le recomendamos que utilice un nivel de temperatura bajo. Si su cabello es espeso, grueso, ondulado o resistente, le recomendamos que utilice un nivel de temperatura alto. ¡Personalice la temperatura, según su tipo de cabello!

FUNDAMENTOS DEL RIZADO

1. Conecte el cable a una toma de corriente 120 V. Oprima el botón ON/OFF (el indicador luminoso empezará a parpadear). El aparato calentará muy rápidamente. Cuando alcance el nivel de temperatura deseado, la luz roja dejará de parpadear. Para apagar el aparato, oprima el botón ON/OFF. **Nunca descuide ni abandone el aparato después de encenderlo.** Para su seguridad, el aparato se apagará automáticamente después de 60 minutos.

2. Divida el cabello seco en secciones uniform y peine cada sección. Abra la tenaza, oprimiendo la manija. Coloque el aparato a medio camino en una sección de cabello y distribuya el cabello uniformemente entre el tubo y la pinza. Suelte la manija para sujetar el cabello. Deslice el aparato suavemente hacia las puntas. Para evitar tener las puntas encrespadas, asegúrese de que estén

IMPLÍCITA. Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

Centro de servicio

Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

Para registrar su producto, visítenos en: www.conair.com/registration Para más información sobre los productos Conair o Infiniti by Conair, llame al 1-800-3-CONAIR o visítenos en www.conair.com/infiniti

©2016 Conair Corporation
150 Milford Road, East Windsor, NJ 08520
7475 N. Glen Harbor Blvd., Glendale, AZ 85307

16PA019337

IB-14233

firmemente posicionadas entre el tubo y la pinza, en la dirección deseada.

Consejo: para rizar el cabello hacia abajo, coloque la sección de cabello debajo de la pinza. Para rizar el cabello hacia arriba, coloque la sección de cabello encima de la pinza.

3. Enrolle el cabello hacia el cuero cabelludo, s permitir que el aparato haga contacto con este. Mantenga la tenaza en esta posición por 8–12 segundos, según la textura y la longitud del cabello. Para obtener rizos apretados y elásticos, divida el cabello en secciones más finas. Para obtener rizos sueltos y naturales, enrolle secciones más gruesas.

4. Desenrolle el cabello lentamente y oprima manija para soltarlo. Permita que el cabello se enfríe antes de peinarlo para “fijar” los rizos.

5. Para peinar el cabello más rápidament oprima el botón turbo. La función turbo aumenta la temperatura en 20 °C/36 °F, para lograr resultados óptimos.

REVESTIMIENTO DE CERÁMICA/TURMALINA

El tubo de la tenaza está cubierto con una capa de cerámica/turmalina increíblemente suave, lo último en tecnología de peluquería. Notará que el cabello se desliza fácilmente sobre el tubo y que es muy fácil limpiar el aparato después de cada uso. El revestimiento de cerámica/turmalina también ayuda a controlar la estática y el frizz. Distribuye el calor uniformemente, para crear peinados sedosos y brillantes, igual que en el salón. Además, no retiene el cabello después de rizarlo.

Es un placer trabajar con esta nueva tecnología, pues facilita el peinado y logra resultados profesionales.

infinitiPRO CONAIR GOLD

TENAZA DE 25 MM CON CERÁMICA/TURMALINA



Instrucciones

Para su seguridad y para disfrutar plenamente de este producto, siempre lea cuidadosamente las instrucciones antes de usarlo.

CONAIR®

Modelo 2014G

