IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER – Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. **Always unplug appliance immediately after using.**
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**
2. **Do not pull, twist, or wrap line cord around appliance.**
3. This appliance should not be used by, on, or near children or individuals with certain disabilities.
4. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
5. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**
6. Keep the cord away from heated surfaces.
7. Never use while sleeping.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Unit is hot when in use. Do not let heated surfaces touch eyes or bare skin.
11. **Do not place the heated unit directly on any surface while it is hot or plugged in. Use the stand provided.**
12. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
13. Do not use an extension cord with this appliance.
14. Do not touch hot surfaces of the appliance. Use handles or knobs.
15. Do not attempt to touch the housing of your appliance near the barrel, as it is hot when in use.
16. This appliance is not a toy. Keep away from children.
17. Do not use with a voltage converter.

SAVE THESE INSTRUCTIONS

OPERATING INSTRUCTIONS

This appliance is intended for household use. Use on Alternating Current (60 hertz) only. This unit is designed to be operated at 120V AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

NOTE: Do not use this styling appliance on hair extensions.

IMPORTANT OPERATING INSTRUCTIONS: Before plugging in your curling iron, be sure to attached and lock a barrel into place. An error message will appear on the display screen if the handle is plugged in without an attachment.

GET TO KNOW YOUR POWER HANDLE

Never leave your styler on and unattended. However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

CERAMIC TECHNOLOGY provides even heat to eliminate damaging hot spots for healthy-looking, shiny hair.

SEAMLESS INTERCHANGEABILITY with power handle that's compatible with all Style Chemistry by Conair® attachments. Includes locking mechanism for safe styling.

HEAT FOR EVERY HAIR TYPE

6 temperature settings and Instant Heat Technology provide styling versatility for all hair types. Use a lower temperature for fine hair and a higher temperature for thick, wavy, or textured hair.

Temperature Control	Hair Type
230°F	Fragile Hair
265°F	Fine Hair
300°F	Average/Medium Hair
335°F	Wavy/Curly Hair
375°F	Thick Hair
400°F	Textured Hair

IMPORTANT! The unit will become very hot when plugged in and switched on. Before removing or attaching an attachment, make sure the appliance has been turned off, unplugged, and cooled.

HOW TO CHANGE ATTACHMENTS

1. Make sure appliance is cool.
2. Turn locking dial to the right to unlock attachment on handle.
3. Pull attachment straight off the handle.
4. Push new attachment into power handle. Counter rest should be flush against locking dial and face downward.
5. Turn locking dial to the left to secure attachment in place.

GETTING STARTED

Select and lock your desired attachment in place. Plug the styler cord into any household outlet (120V). "OFF" will be illuminated on the LED display. Press and hold ON/OFF button for 1–2 seconds to turn on the unit. Press the ON/OFF button repeatedly to select your desired temperature. Once the temperature has stopped blinking on the LED screen, the unit is ready to use. Press and hold ON/OFF button for 1–2 seconds again to power off the unit.

IMPORTANT! Immediately after turning the appliance on, you are able to adjust the temperature. After 5 seconds, the ON/OFF button will automatically lock. To adjust the temperature setting, quickly press ON/OFF button twice to unlock the ON/OFF button. This will deactivate the lock mode and allow the setting to be changed. To turn off the appliance while in lock mode, hold down the ON/OFF button until the appliance switches off.

WARNING: The iron's attachment will get very hot within a few seconds and should not come into contact with the skin after the iron has been turned on.

NOTE: Never leave your iron on and unattended. However, should you fail to turn the iron off, it will shut itself off automatically within 60 minutes.

Always wait for the appliance to cool down before switching attachments.

STYLING TIPS

Hair should be clean and completely dry before using the styler. For best results, use a light styling product before blow-drying hair.

For additional beauty tips, scan QR code below:

Starter Pack
Model CB01
Includes power handle (CB13) and 1 in. curling iron (CB11).

1 in. Flat Iron
Model CB02
Pro Tip: Use a comb as a guide to separate hair strands for better, even heat contact.
The comb also adds gentle tension to the hair for expert straightening.



Round Brush
Model CB03
Pro Tip: Add lift and volume by holding brush at roots for a few seconds before gliding down.

1 in. Bubble Wand
Model CB05
Pro Tip: For bouncy curls, wrap hair around the bubbles. For tight curls, wrap hair between the bubbles.

1¼ – ¾ in. Curling Wand
Model CB06
Pro Tip: Wrap hair in alternate directions for modern waves.

1¼ in. Waver
Model CB08
Pro Tip: For gentle, soft waves, use larger pieces of hair each time you curl.

1¼ in. Curling Wand
Model CB09
Pro Tip: Wrap hair farther apart for loose waves and closer together for defined waves.

1 in. Curling Iron
Model CB11
Pro Tip: Leave the last inch of hair out when curling for a more natural, beachy look.

MEDIDAS DE SEGURIDAD IMPORTANTES

Al usar aparatos eléctricos, especialmente en presencia de niños, siempre se deben tomar precauciones básicas de seguridad, entre ellas las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DEL USO

MANTÉNGALO ALEJADO DEL AGUA

PELIGRO – Cualquier aparato enchufado permanece en tensión, aunque esté apagado. Para reducir el riesgo de electrocución:

1. **Siempre desenchufe el aparato inmediatamente después del uso.**
2. No lo use en el baño o la ducha.
3. No coloque ni guarde el aparato donde pueda caerse o ser empujado a una bañera o un lavabo.
4. No coloque el aparato ni lo deje caer al agua u otros líquidos.
5. Si el aparato se cae al agua, desenchúfelo inmediatamente; **no intente alcanzarlo en el agua.**

ADVERTENCIA – Para reducir el riesgo de quemaduras, electrocución, incendio o lesiones personales:

1. **Nunca descuide/deje el aparato sin vigilancia mientras está enchufado.**
2. **No jale, retuerza ni enrolle el cable alrededor del aparato.**
3. Este aparato no debe ser usado por, en o cerca de niños o personas con ciertas discapacidades.
4. Use este aparato solo para el uso previsto y como se describe en este manual. Solo use accesorios recomendados por el fabricante.
5. **No use este aparato si el cable o el enchufe están dañados, si no funciona correctamente, si está dañado, o después de una caída/caída en agua; devuélvalo a un centro de servicio autorizado para su revisión y reparación.**
6. Mantenga el cable lejos de las superficies calientes.
7. Nunca lo use mientras duerme.
8. Nunca deje caer ni inserte ningún objeto en ninguna de las aberturas.
9. No use este producto en exteriores, ni lo haga funcionar donde se estén usando productos en aerosol (spray) o donde se esté administrando oxígeno.
10. Este aparato se pone muy caliente durante el uso; mantenga los ojos y la piel alejados de las superficies calientes.
11. **No coloque el aparato en ninguna superficie mientras esté caliente o enchufado; use el soporte integrado.**
12. Nunca obstruya los orificios de ventilación, ni coloque el aparato sobre una superficie blanda, tal como una cama o un sofá, donde se puedan obstruir. Mantenga los orificios de ventilación libres de pelusas, cabellos y elementos similares.
13. No use un cable alargador/de extensión con este aparato.
14. No toque las superficies calientes; use los mangos/asas/agarraderas y los botones/perillas/diales.
15. La carcasa del aparato cerca del tubo se pone muy caliente durante el uso; no la toque.
16. Este aparato no es un juguete; manténgalo fuera del alcance de los niños.
17. No use este aparato con un convertidor de voltaje.

GUARDE ESTAS INSTRUCCIONES

INSTRUCCIONES DE USO

Para uso doméstico solamente. Úselo solamente con corriente alterna (60 Hz). Este aparato ha sido diseñado para funcionar con corriente de 120 V AC.

El cable de este aparato cuenta con un enchufe polarizado (una pata es más ancha que la otra). Como medida de seguridad, se podrá enchufar de una sola manera en las tomas de corriente polarizadas. Si no entra en la toma de corriente, inviértalo. Si aun así no entra completamente, comuníquese con un electricista. No intente modificar esta función de seguridad.

NOTA: No use este aparato en cabello sintético/extensiones.

IMPORTANTE: Antes de enchufar el aparato, cerciórese de instalar y bloquear el accesorio deseado. Un mensaje de error aparecerá en la pantalla si el accesorio no está instalado.

FAMILIARÍCESE CON SU ESTILIZADOR

Nunca descuide/deje el aparato sin vigilancia después de encenderlo. Para su seguridad, el aparato se apagará automáticamente después de 60 minutos.

TECNOLOGÍA CERÁMICA – Proporciona calor uniforme para eliminar los puntos calientes dañinos y dejar el cabello brillante y con un aspecto saludable.

ACCESORIOS INTERCAMBIABLES – Mango compatible con todos los accesorios Style Chemistry by Conair®. Sistema de bloqueo para un uso seguro.

TEMPERATURAS PARA TODO TIPO DE CABELLO

6 opciones de temperatura y la tecnología del calentamiento instantáneo proporcionan una mayor versatilidad para todo tipo de cabello. Si su cabello es fino/delgado, use una temperatura más baja. Si es grueso/espeso ondulado o con textura, use una temperatura más alta

Ajuste de temperatura	Tipo de cabello
230 °F	Cabello frágil
265 °F	Cabello fino/delgado
300 °F	Cabello normal/medio
335 °F	Cabello ondulado/ rizado
375 °F	Cabello espeso/grueso
400 °F	Cabello con textura

¡IMPORTANTE! El aparato se pone muy caliente durante el uso. Antes de quitar/instalar un accesorio, desenchufe el aparato y deje que se enfríe.

CÓMO CAMBIAR LOS ACCESORIOS

1. Compruebe que el aparato esté frío.
2. Gire el botón de bloqueo/liberación hacia la derecha para liberar el accesorio.
3. Jale el accesorio para quitarlo.
4. Instale el nuevo accesorio sobre el mango, presionando suavemente. El soporte debe encontrarse directamente contra el botón de liberación y apuntar hacia abajo.
5. Gire el botón de bloqueo/liberación hacia la izquierda para sujetar el accesorio.

FUNCIONAMIENTO BÁSICO

Elija e instale el accesorio deseado. Enchufe el aparato en una toma de corriente de 120 V; "OFF" aparecerá en la pantalla. Mantenga presionado el botón de encendido/apagado por 1-2 segundos para encender el aparato Presione repetidamente el botón ON/OFF para elegir la temperatura deseada. Cuando el indicador luminoso de la temperatura elegida deje de parpadear, el aparato está listo para su uso. Mantenga presionado el botón de encendido/apagado por 1-2 segundos para apagar el aparato.

¡IMPORTANTE! Se puede ajustar la temperatura solamente inmediatamente después de encender el aparato. Después de 5 segundos, el botón de encendido/apagado se bloqueará automáticamente. Para ajustar la temperatura, presione rápidamente el botón de encendido/apagado dos veces; esto desactivará el modo de bloqueo y permitirá ajustar la temperatura. Para apagar el aparato mientras está en el modo de bloqueo, mantenga presionado el botón de encendido/apagado por 1-2 segundos.

ADVERTENCIA: Los accesorios se ponen muy calientes en segundos; evite el contacto con la piel después de encender el aparato.

NOTA: Nunca descuide/deje el aparato sin vigilancia después de encenderlo. Para su seguridad, el aparato se apagará automáticamente después de 60 minutos.

Siempre deje que el aparato se enfríe antes de cambiar los accesorios.

CONSEJOS DE PEINADO

El cabello debe estar limpio y completamente seco. Para obtener resultados óptimos, aplique una loción fijadora ligera en el cabello antes de secarlo.

Para obtener consejos adicionales, escanee este código QR:

Set básico
Modelo CB01
Incluye un mango (CB13) y una tenaza de 1 in (25 mm) (CB11).

Plancha alisadora de 1 in (25 mm)
Modelo CB02
Consejo de pro: Use un peine como guía para separar las secciones de cabello y lograr un mejor y uniforme contacto con el calor.
El peine también estira suavemente el cabello para un alisado experto.



Cepillo redondo
Modelo CB03
Consejo de pro: Levante las raíces y añada volumen dejando el cepillo en la raíz por unos segundos antes de deslizarlo hasta las puntas.

Rizador de burbujas de 1 in (25 mm)
Modelo CB05
Consejo de pro: Para conseguir rizos elásticos, enrolle el cabello alrededor de las burbujas. Para conseguir rizos apretados, enrolle el cabello entre las burbujas.

Rizador de 1¼-¾ in (32-19 mm)
Modelo CB06
Consejo de pro: Enrolle el cabello en direcciones alternas para conseguir ondas modernas.

Ondulador de 1¼ in (32 mm)
Modelo CB08
Consejo de pro: Para crear ondas suaves, rice secciones de cabello más anchas.

Rizador de 1¼ in (32 mm)
Modelo CB09
Consejo de pro: Enrolle el cabello aparte para conseguir ondas sueltas o más cerca para conseguir ondas definidas.

Tenaza de 1 in (25 mm)
Modelo CB11
Consejo de pro: Para crear ondas playeras de aspecto natural, deje 1 in (2.5 cm) de las puntas sin rizar.

FEDERAL COMMUNICATIONS COMMISSION NOTICE

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SUPPLIER'S DECLARATION OF CONFORMITY

Brand: Conair®

Model No.: CB01

Description: Style Chemistry by Conair®

Responsible Party: Conair LLC,
1 Cummings Point Road, Stamford, CT 06902
(203) 351-9000

Standards: FCC Part 15 Subpart B,
ANSI C63.4-2014

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation.

DATE OF ISSUE: 05/28/2024

USER MAINTENANCE

Your appliance is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool, and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service center only. No repairs should be attempted by the consumer.

CAUTION

NEVER allow the power-supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing the cord to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

**WARNING:
IF YOU THINK THE POWER IS OFF WHEN THE SWITCH IS OFF, YOU'RE WRONG.**

KEEP AWAY FROM WATER

Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

LIMITED WARRANTY (U.S. AND CANADA ONLY)

Subject to the exclusions and limitations contained herein, Conair LLC ("Conair") warrants that the Conair® Style Chemistry will be free from material defects in materials and workmanship under normal home use conditions for a period of TWO (2) years beginning on the date the Product was purchased in its original, sealed packaging, unless otherwise specified in this Limited Warranty. This Limited Warranty is only for U.S. consumers (defined herein as purchasers at retail for personal, family, or household use) who originally purchase the Product from Conair or an authorized Conair® reseller (if you are unsure whether a retailer or other point of sale is an authorized or unauthorized Conair reseller, contact Conair).

This Limited Warranty does NOT cover:

- Normal wear and tear;
- Any Product purchased by commercial purchasers or for commercial or non-household uses;
- Accessories, parts, or software added to the Product after the system is shipped from Conair;
- Any costs associated with the replacement or repair of the Product, including labor, installation, or other costs incurred by you without prior Conair approval;
- Damage to the Product, defective conditions, or nonconformities due to: (1) external causes, including shipping, accidents, problems with electrical power (Product designed only for use with 120-volt outlets), abnormal conditions (such as mechanical or environmental); (2) usage not in accordance with Product instructions; (3) misuse, neglect, unauthorized alteration, unauthorized repair; and (4) acts of god or other events beyond Conair's control;
- Though necessary repairs and maintenance might be performed by any company, damage caused by you or any nonauthorized third party, may void, this Limited Warranty;
- Damage caused by accessories or replacement parts not specifically authorized by Conair, may void, this Limited Warranty; and
- Any Product where the original Product identification markings (trademark or serial number) have been removed, altered, or obliterated from the Product.

It is recommended that you visit the website, https://Conair.registria.com, for a fast, efficient way to complete your product registration. However, product registration does not eliminate the need for the consumer to maintain the original proof of purchase to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this Limited Warranty will be the date of manufacture.

HASSLE-FREE WARRANTY

If the Product that is the subject of this Limited Warranty fails during the warranty period for reasons covered by this Limited Warranty, Conair will, at its option, repair the Product, replace the Product with another identical or reasonably equivalent product, or if Conair is unable to repair or replace the Product, refund the purchase price, less the amount directly attributable to the consumer's prior usage of the Product. To obtain a return shipping label, email us at https://www.Conair.com/customer-care/product-assistance/product-inquiry/, or call our Consumer Service Center toll-free at 1-800-3-CONAIR to speak with a representative.

Upon receipt of the Product, Conair will inspect the Product and, if required under this Limited Warranty, attempt to repair, replace, or refund the Product within thirty (30) days. However, there may be delays beyond Conair's control, in which case that time period may be extended as reasonably necessary.

IMPORTANT: If the nonconforming Product is to be serviced by someone other than Conair's Authorized Service Center, please remind the servicer to call our Consumer Service Center at 1-800-3-CONAIR to ensure that the problem is properly diagnosed, the Product is serviced with the correct parts, and the product is still under warranty.

CALIFORNIA RESIDENTS ONLY

The TWO (2) year Limited Warranty period begins on the date the Product was delivered, which may be different than the date the Product was purchased. California residents also have the option of obtaining the benefits of this Limited Warranty by bringing the Product to (A) the store where it was purchased or (B) another retail store that sells Conair products of the same type. The retail store shall then, according to its preference, either repair the Product, refer the consumer to an independent repair facility, replace the Product with another identical or reasonably equivalent product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the Product. California residents may also, according to their preference, return nonconforming products directly to Conair for repair or, if necessary, replacement with another identical or reasonably equivalent product by calling our Consumer Service Center toll-free at 1-800-3-CONAIR. Conair will be responsible for the cost of such repair, replacement, and/or shipping and handling for such nonconforming products under warranty.

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE OR BY JURISDICTION. IN THE EVENT THIS LIMITED WARRANTY IS BREACHED, YOU MAY HAVE CLAIMS FOR REPLACEMENT, DAMAGES, OR OTHER PENALTIES. LIMITATIONS OF LIABILITY/ADDITIONAL LIMITATIONS AND EXCLUSIONS. ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIMITED WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU. CONAIR'S RESPONSIBILITY UNDER THIS OR ANY OTHER WARRANTY, IMPLIED OR EXPRESS, IS LIMITED TO REPAIR, REPLACEMENT, OR REFUND, AS SET FORTH ABOVE. THESE REMEDIES ARE THE SOLE AND EXCLUSIVE REMEDIES FOR ANY BREACH OF WARRANTY. TO THE MAXIMUM EXTENT PERMITTED BY LAW, CONAIR IS NOT RESPONSIBLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, LOSS OF GOODWILL, DAMAGE TO OR REPLACEMENT OF EQUIPMENT AND PROPERTY, AND ANY COSTS OF RECOVERING, REPROGRAMMING, OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH A SYSTEM CONTAINING THE PRODUCT), EVEN IF CONAIR HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. ALL EXPRESS AND IMPLIED WARRANTIES ARE LIMITED IN DURATION TO THE LIMITED WARRANTY PERIOD. NO WARRANTIES APPLY AFTER THAT PERIOD. SOME STATES (OR JURISDICTIONS) DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THIS LIMITATION MAY NOT APPLY TO YOU.

This Limited Warranty is issued by:

Conair LLC
1 Cummings Point Road
Stamford, CT 06902
1-800-3-CONAIR

BEAUTY TIPS

To achieve the looks you love and for more great Conair® products, visit www.conair.com

Please register this product at register.conair.com

For info on any Conair® product, call **1-800-3-CONAIR** or visit us on the web at **www.conair.com**

Service Center
Conair LLC
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

©2024 Conair LLC

24PA000041

IB-18565

Style Chemistry by CONAIR

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Instructions & Styling Guide

Models CB01 (CB11+CB13) **/ CB02 / CB03 / CB05 / CB06 / CB08 / CB09 – All Versions**