

# IMPORTANT SAFETY INSTRUCTIONS

**THIS APPLIANCE IS INTENDED FOR HOUSEHOLD USE. WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:**

**WARNING**—To reduce the risk of burns, electrocution, fire, or injury to persons:

1. Read all instructions before using the appliance.
2. To protect against electrical hazards, do not use while bathing or in the shower.
3. This appliance should not be used by or near children or by individuals with certain disabilities.
4. Unplug the appliance from outlet when not in use and before cleaning. Do not leave appliance unattended when it is plugged in. Keep cord away from heated surfaces.
5. Do not operate this appliance with a damaged cord or plug or if the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to nearest service facility for examination, electrical or mechanical adjustment, or repair. No repairs should be attempted by the consumer.
6. Use appliance only for intended use as described in this instruction book. The use of attachments not recommended or sold by Conair may cause hazards.
7. Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
8. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
9. Do not use on a soft surface such as a bed, where openings may be blocked.

10. Turn switch to "OFF" position allow unit to cool and unplug cord before replacing light bulbs.
11. Do not place or store appliance where it can fall or be pulled into a tub or sink.
12. Do not place in or drop into water or other liquid.
13. If an appliance falls into water, unplug it immediately. Do not reach into the water.
14. Do not use a bulb greater than 3 watts.

Use on any 120 volt 60 hertz AC electric outlet (ordinary house current). Do not use it on any other electrical outlet.

## SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

**CAUTION: BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.**

1. Your lighted makeup mirror will swivel so that you can use either the normal, flat mirror or the 7x magnifying mirror located on the opposite side.
2. Plug adaptor into any standard 120 volt wall outlet. To turn on lights, simply turn the switch on the base to desired light setting. This Classique® Collection Mirror is equipped with low, medium, high settings switch which allows you to gradually increase or decrease light intensity for the ideal illumination.
3. After use, always turn switch to the "OFF" position and unplug.
4. The beauty and design of the Classique®



Collection mirror complement any decor. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see "STORAGE" for detailed information.

### A.C. ADAPTER

**NOTE: UNIT SUPPLIED WITH A UL LISTED 7.5VAC ADAPTER. FOR MORE INFORMATION, PLEASE CONTACT A CONAIR SERVICE CENTER.**

### TO REPLACE BULB

**CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 3 MINUTES BEFORE REPLACING BULB. Replace bulb only with bulb of same wattage rating.**

Contact a Conair service center at 1-800-3 CONAIR for replacement bulb information (ask for replacement bulb [#RP108]). Bulbs are \$1.50 a piece, includes shipping and handling.].

1. Remove screws from left and right sides of mirror. (Fig. 1)

2. Carefully lift off the removable housing from the half that is affixed to the stand.
3. Unscrew the old bulb and replace with the new bulb. (Fig. 2)
4. Carefully replace the removable half after locating and aligning the screw holes to the fixed half.
5. Insert screws into screw holes and tighten.



Figure 1




Figure 2

## STORAGE

Disconnect from electrical outlet. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED. Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where mirror will not be damaged.

Handle cord carefully for longer life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord or a short circuit. To store mirror, coil cord loosely.

## MAINTENANCE


Your lighted mirror is designed for household use and is virtually maintenance-free. No lubrication is needed.

If cleaning becomes necessary, disconnect the appliance from the power source and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. Do not light until you are certain mirror is completely dry.

If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

**WARNING:  
IF YOU THINK THE  
POWER IS OFF  
WHEN THE SWITCH  
IS OFF,  
YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically alive even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG  
SMALL APPLIANCES**

Public Service AD from Association of Home Appliance  
Manufacturers and Underwriters Laboratories, Inc.

## LIMITED ONE YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below that is nearest you, together with your purchase receipt and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-366-0937 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12 MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

©2004 Conair Corporation

Service Centers:

Conair Corporation  
Service Department  
150 Milford Road,  
East Windsor, NJ 08520

Conair Corporation  
Service Department  
2 North 59th Avenue  
Phoenix, AZ 85043

04NP135

IB-5191

## Double-sided Lighted Makeup Mirror With 3 Light Settings



### Use and Care Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

**CONAIR®**  
Model BE51