

# IMPORTANT SAFETY INSTRUCTIONS

This lighted mirror has a polarized plug (one blade is wider than the other). As a safety feature, to reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

**THIS APPLIANCE IS INTENDED FOR HOUSEHOLD USE. WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:**

## WARNING

To reduce the risk of burns, electrocution, fire, or injury to persons:

1. Read all instructions before using the appliance.
2. To protect against electrical hazards, do not use while bathing or in the shower.
3. This appliance should not be used by or near children or individuals with certain disabilities.
4. Unplug the appliance from outlet when not in use and before cleaning. Do not leave appliance unattended when it is plugged in. Keep cord away from heated surfaces.
5. Do not operate this appliance with a damaged cord or plug or if the appliance malfunctions or has been dropped or damaged in any manner. Return appliance to nearest service facility for examination, electrical or mechanical adjustment or repair. No repairs should be attempted by the consumer.
6. Use appliance only for intended use as described in this instruction book. The use of attachments not recommended or sold by Conair may cause hazards.
7. Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen

is being administered.

8. Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause fire.
9. Do not drop or insert any object into any opening as this may cause an electrical hazard. Do not drape clothes over mirror.
10. Do not block openings. Do not use on a soft surface such as a bed, where openings may be blocked.
11. Turn switch to Off position and unplug cord before replacing light bulbs.
12. Do not place or store appliance where it can fall or be pulled into a tub or sink.
13. Do not place in or drop into water or other liquid.
14. If an appliance falls into water, unplug it immediately. Do not reach into the water.
15. Use on any 120 volt, 60 hertz AC electric outlet (ordinary house current). Do not use it on any other electrical outlet.

## SAVE THESE INSTRUCTIONS

### INSTALLATION INSTRUCTIONS

#### Wall Mount Mirror

1. Remove mounting bracket from base or mirror. Leave long screws in bracket.
2. Using  $\frac{3}{8}$ " drill size, drill two holes in wall the same distance apart as two opposite slots in bracket. Screw into wall stud if possible. If drilling into stud, use  $\frac{1}{8}$ " drill size. Otherwise, insert two wall anchors in holes.

**CAUTION: Do not drill into electrical wiring through wall. Check with electrician if necessary.**

3. Screw bracket onto wall, into the anchors.
4. Attach mirror to bracket by placing long screws through the two holes in mirror's base. Secure

with knurled nuts. Cord should be facing floor.

## OPERATING INSTRUCTIONS

1. Your lighted makeup mirror features a 1x and 6x magnification for the 7.5" mirror head. The 1x magnification also features an 8x magnification inset for detail work.
2. Your lighted makeup mirror will adjust to many different angles. Simply tilt the neck or head backward or forward to adjust to the desired angle. Your mirror will also swivel so that you can use either the normal, flat mirror or the magnifying mirror located on the opposite side.
3. Plug into any standard wall outlet (120 Volt AC). Turn the rotary switch clockwise to the On position.
4. After use, turn switch clockwise again to the Off position.

### TO REPLACE BULB

**CAUTION: TURN OFF POWER AND UNPLUG. ALLOW TO COOL AT LEAST 3 MINUTES BEFORE REPLACING BULB.**

**NOTE:** Do not use a bulb greater than 20 watts. Contact a Conair service center at 1-800-3 CONAIR for replacement bulb information (ask for replacement bulb RP109). Bulbs are \$1.50 each including shipping and handling.

1. Unscrew screws from opposite sides of the mirror housing near the rotating hinges (Fig. 1).
2. Carefully lift off the top half of the housing from the bottom half that is affixed to the arm.
3. Unscrew the old bulb and replace with the new bulb (Fig. 2).
4. Carefully replace the top housing half after locating and aligning the screw holes to the




Figure 1




Figure 2

bottom half. If the holes don't line up, turn top half of mirror 180°.

5. Insert two screws back into screw holes and tighten with screw driver. Do not over-tighten.

## MAINTENANCE

Your lighted mirror is designed for household use and is virtually maintenance-free. No lubrication is needed.

If cleaning becomes necessary, disconnect the appliance from the power source, allow to cool, and wipe exterior with a damp cloth. Clean mirror surfaces with a glass cleaner. To protect against electrical hazards, do not light until you are certain mirror is completely dry.

If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair.


## STORAGE

Disconnect from electrical outlet. **BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MAGNIFYING SIDE OF MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.** Allow to cool to room temperature before storing. Place in cool, dry area out of reach of children, where it will not be damaged.

Handle cord carefully for to prolong its life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord and the mirror could short circuit. To store mirror, coil cord loosely.

**WARNING:  
IF YOU THINK  
THE POWER IS  
OFF WHEN THE  
SWITCH IS OFF,  
YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically alive even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG  
SMALL APPLIANCES**

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

## LIMITED ONE-YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or material.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-326-6247 for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

©2006 Conair Corporation

Service Center  
Conair Corporation  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85043

06PM8015

IB-7019

Model BE9

**Lighted  
Wall Mount Mirror**  
Double-Sided: 1x/6x Magnification  
with 8x Magnification Inset Mirror



**CONAIR**<sup>®</sup>

THE CLASSIQUE<sup>®</sup> COLLECTION

MODEL BE9 WALL-MOUNT

MIRROR SERIES