

# IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

## READ ALL INSTRUCTIONS BEFORE USING *KEEP AWAY FROM WATER*

### DANGER

- Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. **ALWAYS UNPLUG APPLIANCE IMMEDIATELY AFTER USING.**
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into, water or other liquid.
5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**

### WARNING

- To reduce the risk of burns, electrocution, fire, or injury to persons:

1. **This appliance should never be left unattended when plugged in.**
2. Do not pull, twist, or wrap line cord around appliance even during storage.
3. This appliance should not be used by, or near children or individuals with certain disabilities.

4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

**5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center for examination and repair.**

6. Keep the cord away from heated surfaces.

7. Never use while sleeping.

8. Never drop or insert any object into any opening.

9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

10. Unit is hot when in use. Do not let heated surfaces touch eyes or skin.

11. Do not place the heated straightener directly on any surface or on the appliance power cord while it is hot or plugged in.

12. Never block the air openings of the appliance or place on a soft surface such as a bed or couch, where the air openings may be blocked. Keep the air opening free of lint and other debris.

13. Do not use an extension cord with this appliance.

14. Do not touch hot surfaces of the appliance. Use handles or knobs.

15. Do not attempt to touch the housing of your appliance near the straightening plates, as it is hot when in use.

16. Before plugging in, read the information about dual voltage contained in the instruction section of this manual.

17. Do not use with a voltage converter.

# SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This straightening iron is intended for household use. Use on Alternating Current (50/60 hertz) only. This unit is designed to be operated at 120/240 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

#### TO USE CORD REEL

Before plugging into the wall receptacle, pull cord from the cord reel to cord marking.

**DO NOT PULL CORD OUT OF REEL WHILE PLUGGED INTO WALL SOCKET AS YOU MAY DAMAGE THE WALL SOCKET.**

#### TO RETRACT CORD

Unplug from wall receptacle and press the retract button. Cord will retract into cord reel for easy storage.

#### DUAL VOLTAGE

This straightening iron will automatically adjust to the proper voltage. Use an adapter plug with correct configuration prior to use in outlet.

#### STRAIGHTENING BASICS

Plug the straightening iron cord into any household outlet (120/240V). Press ON button. Red and green lights will blink alternately. When ready to use, green light will remain on and red light will turn off. The iron will heat up very quickly. To turn off, press OFF button. Green light will go off. Red light will remain on as a safety precaution to indicate the iron is still plugged in.

Never leave your straightening iron on and unattended. However, should you fail to turn the unit off, it will shut itself off automatically within 60 minutes.

**WARNING: The straightening iron's Nano Silver Ceramic-coated plates will get very hot within a few seconds and should not be placed in contact with the skin after the straightening iron has been turned on.**

#### Temperature Setting Guide

TEMPERATURE CONTROL	HAIR TYPE
Low	Delicate, thin, easy-to-straighten hair
Medium	Average-to-thick or treated hair
High	Wavy or hard-to-straighten hair

# IMPORTANT

To ensure correct contact, hold plates together when inserting into power base. Be careful to avoid contact with hot surfaces.

#### INSTANT HEAT TECHNOLOGY

The iron's unique high temperature settings and Instant Heat technology provide styling versatility for all hair types. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-straighten hair, keep the heat setting on high.

For best results, use a light styling product before blow-drying hair. Start with a hair section that is 1½" wide and no more than ½" thick. Open the iron and place a hair section between the two hot plates, close to the scalp. Trap hair between the plates by firmly squeezing the handles with heat shields in place. While maintaining the tension, slowly pull the unit down along the hair section toward the end of hair. At the end of hair section, release the pressure on the handle and allow the hair section to slide out. Repeat process on additional sections of hair until you achieve the hair style you desire. It may be necessary to repeat process on certain areas, depending on the texture of your hair.

Some experience is necessary when learning to use this straightening iron. After using the iron several times, you will learn the ideal way to straighten and style your hair.

#### FLOATING PLATES

Your straightener provides a more uniform contact with the hair as the floating plates self adjust. These plates allow better contact, giving straighter results.

#### STYLING WITH NANO SILVER CERAMIC-COATED PLATES

The plates of your new straightening iron have Nano Silver Ceramic-coated surface, the newest technology.

You'll also find that hair glides easily over the surface of the plates as you're straightening. The Nano Silver Ceramic-coated surface also helps smooth down flyaways and frizzies. As you smooth each strand, heat is evenly distributed so that the style you create has a salon-perfect, silky smooth, shining finish. Hair slips right off the plates after it's straightened.

The new Nano Silver Ceramic technology is a pleasure to work with, makes styling your hair easier and provides more professional results.

You'll find not only that hair glides easily over the surface of the plates as you're straightening, but it's simpler to clean styling product residue, etc. off after each use.

#### USING INSTANT HEAT & THE UNIFORM HEAT RECOVERY SYSTEM

This straightening iron features Conair's Instant Heat technology. It heats up to the temperature you've selected for your hair type.

Within this Instant Heat technology, there are 3 temperature settings for every type of hair, from the finest to the curliest and most resistant. Use the low settings for easy-to-straighten hair, the medium setting for thick hair and the high setting for wavy or hard-to-straighten hair.

And that's not all. Conair's professional salon standards of engineering provide you with a Uniform Heat Recovery System that maintains the straightening iron at a constant temperature.

There is a constant surge of power to ensure that heat is continuously delivered for optimal styling results, unlike other units which lose heat during use. This provides consistent styling power so that every strand of your hair is set with the same level of heat and comes out the same way for a perfect finish.

## GET TO KNOW YOUR STRAIGHTENING IRON



## USER MAINTENANCE

Your straightening iron is virtually maintenance-free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an authorized service representative only. No repairs should be attempted by the consumer.

### CAUTION


NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

### STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. **Do not jerk or strain cord at plug connections.** Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

**WARNING:**  
**IF YOU THINK THE**  
**POWER IS OFF, WHEN**  
**THE SWITCH IS OFF**  
**YOU'RE WRONG.**

**KEEP AWAY FROM WATER**



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG**  
**SMALL APPLIANCES**

## LIMITED TWO-YEAR WARRANTY

Conair will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials. To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture. **ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.**

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

### Service Center

Conair Corporation  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

For information on any Conair® product call 1-800-3-CONAIR or visit us on the web at: [www.conair.com/infinite](http://www.conair.com/infinite)

©2009 Conair Corporation  
150 Milford Road, East Windsor, NJ 08520  
7475 N. Glen Harbor Blvd., Glendale, AZ 85307  
Patent Pending

08PA11590

IB-9031

# nano silver ceramic

1" STRAIGHTENER



## Instruction & Styling Guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

# CONAIR®

Model CS85

\* When compared to other Conair® straighteners