




...can save a life!

# GROUND FAULT CIRCUIT INTERRUPTERS

This message about...



**IF YOU MUST USE YOUR HAIR DRYER IN THE BATHROOM, INSTALL A GFCI\* NOW!**

Your local electrician can help you decide which type is best for you—a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCIs in the bathrooms, garages, and outdoor outlets of all new homes.

don't mix. If your hair dryer falls into water while it's plugged in, the electric shock can kill you... even if the switch is "off." A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.



**A GFCI can save your life! Compared to that, the price is small! Don't wait... install one now!**

\*GFCI is a sensitive device which reacts immediately to a small electric current leak by stopping the electricity flow.

certain countries.

positions. A plug adapter may be necessary in certain countries. When not in use, your dryer should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer.

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

**FOR 110-125 Volt Operation**

With the main switch in the off position, turn the dual voltage switch to the 125 position. In this position, the dryer operates on all available heat settings. Confirm the voltage available at each overseas location before using the appliance. For use in several countries overseas, the voltage selector may need to be placed in the 250 position. Confirm the voltage available at each overseas location before using the appliance. For connection to a 240 volt supply, use an attachment plug adapter of the proper configuration for the power supply receptacle.

**FOR DUAL VOLTAGE DRIVERS**

**ADDITIONAL INFORMATION**



# CONAIR®

Manual de Instrucciones y  
Guía de Modelado  
Modelo 157RDR/157L



Linea Gratis  
de Asistencia

Llame al: 1-800-3-CONAIR  
O visítenos en la web en:  
<http://www.conair.com>

Para obtener información sobre  
cualquier producto de Conair

CENTRO DE SERVICIO

CONAIR CORPORATION  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

©2006 CONAIR CORPORATION  
150 Milford Road, East Windsor, NJ 08520  
7475 N. Glen Harbor Blvd., Glendale, AZ 85307  
Impreso en la China  
06PD3088

IB-7084

When not in use, your dryer should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. Do not wrap line cord around dryer.

## STORAGE

If the cord or dryer is damaged or does not operate properly, return it for repair to the nearest service center. No repairs should be attempted by the consumer.

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. Stop use immediately if damage is visible or unit stops or operates intermittently.

## CAUTION

Your dryer is virtually maintenance-free. No lubrication is needed. For proper operating performance, the dryer must be kept clean. Blocked or clogged air intake vents will cause the dryer to overheat. When cleaning is needed, unplug the cord, let it cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a cloth only.

**USER MAINTENANCE**

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24 MONTH DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24 MONTH DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

CONAIR will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

CONAIR will repair or replace, at our option, your appliance free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

**LIMITED TWO YEAR WARRANTY**

## INSTRUCCIONES DE MANTENIMIENTO

Su secador casi no necesita mantenimiento. No necesita lubricación. Para que funcione correctamente, debe mantenerlo limpio. El secador se recalentará si las aberturas de aire están bloqueadas u obstruidas. Cuando sea necesario limpiarlo, desenchufe el aparato y déjelo enfriar, luego saque el polvo y las pelusas de las aberturas de aire con un cepillo pequeño o el cepillo accesorio de una aspiradora. La superficie exterior del secador sólo se debe limpiar con un paño limpio.

## PRECAUCIÓN

NUNCA jale, retuerza ni doble mucho el cable eléctrico. Nunca lo enrolle con fuerza alrededor del secador. Esto pudiera dañar la junta flexible que lo conecta al secador, produciendo su ruptura o un cortocircuito. Inspeccione el cable con frecuencia para asegurarse que no está dañado. Deje de usar el aparato inmediatamente si el cable parece dañado, si el aparato deja de funcionar o funciona de manera intermitente. Si el cable o el aparato está dañados o no funcionan correctamente, regrese el aparato a la tienda donde lo compró, o llévelo a un centro de servicio autorizado únicamente. No trate de repararlo.

## ALMACENAMIENTO

Quando non utilizza el aparato, desconéctelo, déjelo enfriar y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. No enrolle el cable alrededor del aparato.

## INFORMACIÓN ADICIONAL PARA LOS SECADORES BITENSIÓN

Coloque el selector de voltaje sobre 125 para uso en los Estados Unidos. Para uso en países con sistemas eléctricos de 250 voltios, coloque el selector en 250. Averigüe el nivel de la corriente antes de usar el aparato. Para usar el aparato con un sistema de 240 voltios, use el adaptador adecuado.

### Operación 110-125 Voltios

Coloque el selector de voltaje sobre 125. El aparato funcionará con todos los ajustes de calor y de velocidad disponibles.

### Operación 220-250 Voltios

Coloque el interruptor en la posición L0 y el selector de voltaje sobre 250. El aparato funcionará con calor y velocidad altos únicamente. **No cambie la velocidad o la selección de voltaje cuando use el aparato con un sistema de 220-250 voltios. Deje los interruptores en las posiciones L0 y 250.** Un adaptador puede ser necesario en ciertos países.

©2006 CONAIR CORPORATION  
150 Milford Road, East Windsor, NJ 08520  
7475 N. Glen Harbor Blvd., Glendale, AZ 85307  
Printed in China  
06PD3088

CONAIR CORPORATION  
Service Department  
7475 N. Glen Harbor Blvd.  
Glendale, AZ 85307

SERVICE CENTER:



Hotline  
Call: 1-800-3-CONAIR  
Or visit us the web at:  
<http://www.conair.com>  
For info on any Conair product

Instruction and Styling Guide  
Model 157RDR/157L



Este mensaje sobre los ...

# GROUND FAULT CIRCUIT INTERRUPTERS

(Interruptores de circuito contra fallas a tierra)

...¡Puede salvar una vida!

**¡SI DEBE USAR EL SECADOR EN EL CUARTO DE BAÑO, INSTALE UN GFCI\* AHORA!**

Su electricista le puede ayudar a decidir cual sistema escoger – un sistema amovible que se conecta a la toma de corriente, o un sistema permanente que él instalará. El Código Nacional de Electricidad ahora exige que todos los enchufes ubicados en los cuartos de baño, los garajes y las partes exteriores de las casas nuevas sean equipados con CGFI.

**¿POR QUÉ NECESITA UN GFCI?** La electricidad y el agua no deben juntarse. Si su aparato cae al agua mientras está conectado, una descarga eléctrica puede causar su muerte... incluso cuando el interruptor está apagado. Un fusible o un interruptor de circuito estándar no le protegerá en tal situación. Un GFCI le ofrece más protección.



**¡Un GCFI le puede salvar la vida! ¡Comparado con ella, el precio es bajo! ¡No espere... instale uno ahora mismo!**

\*Un GCFI es un dispositivo sensible que reacciona inmediatamente a una pequeña pérdida de corriente, deteniendo el flujo de electricidad.