

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER — Any appliance is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock:

1. **Always unplug appliance immediately after using.**
 2. Do not use while bathing or in the shower.
 3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
 4. Do not place in or drop into water or other liquids.
 5. If an appliance falls into water, unplug it immediately. **Do not reach into the water.**
- WARNING** — To reduce the risk of burns, electrocution, fire, or injury to persons:
1. **This appliance should never be left unattended when plugged in. Do not pull, twist, or wrap line cord around appliance.**
 2. This appliance should not be used by, on, or near children or individuals with certain disabilities. Use could result in fire or personal injury.

3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

4. **Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a Conair Service Center for examination and repair.**

5. Keep the cord away from heated surfaces. Do not pull, twist, or wrap line cord around appliance, even during storage.
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
7. Never use while sleeping.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord to operate hot air styler.
11. Do not direct hot air toward eyes or other heat-sensitive areas.
12. Attachments may be hot during use. Allow them to cool before handling.
13. Do not place appliance on any surface while in use.
14. While using the appliance, keep your hair away from the air inlets.
15. Do not operate with a voltage converter.

16. **TO AVOID TANGLING, NEVER ROLL THE HAIR AROUND THE HOT AIR BRUSH MORE THAN TWO TIMES.**

17. This appliance is not a toy. Keep away from children.

SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS

This appliance is intended for household use only. Use on Alternating Current (60 hertz) only. Standard hot air stylers are designed to operate at 110 to 125 volts AC.

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

NOTE: Do not use this styling appliance on hair extensions.


CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE APPLIANCE

This appliance is equipped with an Appliance Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water. To make sure the ALCI is functioning properly, perform the following test. The purpose of this test is to allow you to make sure the water sensing system (ALCI) is working.

1. Plug in the appliance and press test button on plug (see diagram).
2. The appliance will stop working. There will be an audible click and reset button will pop out. This indicates the ALCI is functioning properly.
3. To reset ALCI with a reset button, unit should be unplugged. Then push reset button in and reinsert plug into outlet.
4. **If ALCI is not functioning properly, return appliance to service center.**
5. It is important that if immersion occurs, this unit be brought to a service center. Do not try to reset.
6. Be sure to repeat test every time you use the unit to confirm ALCI is operational.

Should the appliance go off and the reset button pop up during use, this could indicate a malfunction in the unit. Remove plug from outlet and allow the appliance to cool. Reinsert plug into outlet.

The appliance should then function normally. If not, return it to an authorized Conair Service Center for evaluation and repair.



DOUBLE CERAMIC TECHNOLOGY

The barrel of your 1¼ hot air styler brush has an Easy-Glide™ double ceramic-coated surface, the newest technology.

This double ceramic-coated surface helps to smooth down flyaways. As you wind each strand around the barrel, it evenly distributes heat so that the style you create has a salon perfect, silky smooth, shiny finish. Hair glides easily over the surface of the barrel. Any residue from styling products that builds up on the ceramic-coated barrel can be easily cleaned.

GETTING STARTED

After shampooing your hair, towel-dry and untangle it carefully with a large-toothed comb. Always start untangling your wet hair at the tips, then gradually work your way up. Gentle untangling prevents split ends from forming. Now finish drying and styling your hair using your hot air styler. Make sure your desired attachment is locked into place. Plug styler into outlet. Slide switch to turn appliance on and off.

To avoid tangling, never roll the hair around the hot air brush more than two times. Also, use a small section of hair at a time.

FEATURES

- 1000 watts
- High-shine, ionic conditioning
- 2 heat settings
- Professional power cord
- 1¼ in. brush to curl or straighten
- ¾ in. nylon & boar bristle brush to curl
- Concentrator for silky-straight results

HEAT/SPEED SETTINGS

Low Setting: Ideal airflow for medium, normal hair.

High Setting: Combines ideal airflow with higher temperature for thick hair.

GET TO KNOW YOUR STYLER



TO STYLE HAIR

1. After detangling hair, section damp hair into 4 to 8 equal parts, depending on hair type. Use sectioning clips to section hair for easy styling.
2. Select heat setting based on hair type and desired effect.

USING THE 1¼ ATTACHMENT TO CURL AND STRAIGHTEN

Beginning at the crown area, take a section of hair and place the 1¼ in. brush near the root area. Slide the hot air brush toward the ends, then wind toward the root area. Hold for approximately 10 seconds, then gently unwind the hair without tension. Continue throughout the hair until styled as desired.

USING THE ¾ NYLON BRUSH TO CURL

Position the brush under hair, close to the roots. Slide it down to hair ends. This will give perfect shape to your hairstyle, while bristles and hot air create a polished finish and add shine

USING THE CONCENTRATOR FOR VOLUME

Build volume by directing the airflow at roots, against the natural growth pattern.

bc171n_21pa077481_double_ceramic_ib_final.indd 1



IMPORTANT

Never immerse this product in water or any other liquids.

IF YOU MUST USE YOUR HOT AIR STYLER IN THE BATHROOM, INSTALL A GFCI* NOW!

Your local electrician can help you decide which type is best for you – a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCIs in the bathrooms, garages, and outdoor outlets of all new homes.

WHY DO YOU NEED A GFCI? Electricity and water don't mix. If your hot air styler falls in water while it's plugged in, the electric shock can kill you... **even if the switch is off.** A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.

A GFCI can save your life! Compared to that, the price is small! Don't wait... install one now!

*GFCI is a sensitive device that reacts immediately to a small electric current leak by stopping the electricity flow.



GROUND
FAULT
CIRCUIT
INTERRUPTERS

...can save a life!

CLEANING & MAINTENANCE

- Unplug the appliance and let cool completely before cleaning it.
- Use a damp cloth to clean carefully. Make sure the appliance is completely dry before using again.
- The rear filter should be cleaned on a regular basis using a soft brush to help prevent buildup and overheating. This will also prolong the motor life.

USER MAINTENANCE

Your hot air styler is virtually maintenance free. No lubrication is needed. For proper operating performance, the hot air styler must be kept clean. When cleaning is needed, unplug the cord, allow to cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the hot air styler should be wiped clean with a cloth only. **Blocked or clogged air intake vents will cause the hot air styler to overheat.** If overheating occurs, an automatic safety device will shut the hot air styler or the heat off to prevent damage or personal injury. If the unit or the heat turns off, unplug the cord and allow the hot air styler to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

CAUTION

NEVER allow the power supply-cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the hot air styler. Damage will occur at the high flex point of entry into the hot air styler, causing it to rupture and short circuit. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**


If the cord or hot air styler is damaged or does not operate properly, return it for repair to an authorized Conair service representative only. No repairs should be attempted by the consumer.

STORAGE – IMPORTANT

When not in use, your hot air styler should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. Do not wrap line cord around hot air styler. Allow the cord to hang or lie loose and straight at the point of entry into the hot air styler.

**WARNING:
IF YOU THINK
THE POWER IS OFF
WHEN THE SWITCH
IS OFF,
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electric appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

**ALWAYS UNPLUG
SMALL APPLIANCES**

LIMITED ONE-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials. To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

2/1/21 11:12 AM

DOUBLE CERAMIC



3-IN-1 HOT AIR BRUSH

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

BEAUTY TIPS:
To achieve the looks you love and for more great Conair® products, visit www.conair.com

Service Center
Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

Please register this product at www.conair.com/registration

For information on any Conair product, call 1-800-3-CONAIR or visit us on the web at www.conair.com.

©2021 Conair Corporation

21PA077481

IB-17173

CONAIR

Instructions & Styling Guide

Model BC171N – All Versions

bc171n_21pa077481_double_ceramic_ib_final.indd 2

2/1/21 11:12 AM

