

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING THE MINI DISPOSABLE SILICONE FACIAL BRUSH

WARNING — To reduce the risk of burns, fire, electric shock, or injury to persons:

1. Close supervision is required when this product is used on, by or near children or people with certain disabilities.
2. Use this product only for its intended use as described in this instruction booklet.
3. Keep the unit away from heated surfaces.
4. Never use while sleeping or drowsy.
5. Do not use outdoors or where oxygen is being administered.
6. Never operate if the product is damaged.
7. Not for use by children.
8. Water resistant: Can be rinsed in the shower, but not submerged.
9. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Conair.
10. Never drop or insert any object into the product.

USER MAINTENANCE INSTRUCTIONS

CARING FOR YOUR TRUE GLOW® MINI DISPOSABLE SILICONE FACIAL BRUSH

1. After each use, rinse brush head and wipe with a damp cloth to remove any oils or lotions used during treatment.
2. Clean entire unit thoroughly each week using warm, soapy water to help remove oil and lotion buildup, rinse and wipe with a dry cloth. Store unit in its box or in a clean, dry place.
3. Do not use abrasive cleaners for cleaning.
4. Do not put unit in dishwasher for cleaning.

STORAGE

When not in use, you should turn off the facial brush and store it in a safe, dry location, out of reach of children.

11. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
12. Children should be supervised to ensure that they do not play with the appliance.
13. This product contains button cell batteries that are non-replaceable. Do not attempt to open unit to change batteries.
14. This product contains two button cell batteries. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately.

SAVE THESE INSTRUCTIONS

The True Glow® Mini Disposable Silicone Facial Brush has no serviceable parts.

SENSITIVITY AND CAUTIONS SPECIAL CAUTIONS FOR DELICATE AREAS

The True Glow® Mini Disposable Silicone Facial Brush is a facial cleansing device that is intended to help you get clean and healthy-looking skin. The True Glow® Mini Disposable Silicone Facial Brush is not a medical device and is not intended to be used to treat any medical conditions such as acne.

If you are under a doctor's care for any skin condition or if you think you have very sensitive skin, please consult your physician before use.

We recommend not sharing the brush; each user should have their own brush.

INSTRUCTIONS FOR USING BATTERIES

1. **This product contains button cell batteries that are non-replaceable. Do not attempt to open unit to change batteries.**
2. **This product contains two button cell batteries. If swallowed, it could cause severe injury or death in just 2 hours. Seek medical attention immediately.**
3. **Tell others about the risk associated with button cell batteries and how to keep their children safe.**
4. **Keep batteries out of reach of children.**
5. **Remove used batteries promptly. Dispose of used batteries immediately and safely in accordance with applicable regulations. They should be disposed of in a location specifically designated for that purpose, so they can be recycled safely and without posing any risk for the environment. Do not burn or bury them. Flat batteries can still be dangerous.**

CONTAINS SEALED BUTTON CELL BATTERIES.

Do not use with exfoliation creams with rough or jagged particles.

Removing makeup can cause the brush to discolor. This will not affect performance or the brush.

If you experience any pain or discomfort during use, stop using and consult your physician.

Moisten your face and apply cleanser. Also apply a small amount of cleanser to the moistened brush. Do not apply pressure with the brush to the face; let the oscillation perform the cleansing. When finished, rinse with water and dry skin with a clean towel.

TRUE GLOW® MINI DISPOSABLE SILICONE FACIAL BRUSH FEATURES



OPERATING INSTRUCTIONS

The True Glow® Mini Disposable Silicone Facial Brush operates on 2 button cell batteries (included).



STARTING THE MINI DISPOSABLE SILICONE FACIAL BRUSH

Press the ON/OFF button one time to turn on the Silicone Facial Brush.

STOPPING THE MINI DISPOSABLE SILICONE FACIAL BRUSH

Press ON/OFF button one time to stop the unit.

LIMITED ONE-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

FACIAL
cleansing zones



NOTE: USE FOR 10 SECONDS AT EACH LOCATION

INSTRUCTIONS FOR USING THE MINI DISPOSABLE SILICONE FACIAL BRUSH

1. Wet your face and apply sufficient cleanser. Also apply a small amount of cleanser to the wet brush.
2. Press the ON/OFF button one time to start the Mini Disposable Silicone Facial Brush. We recommend using the Disposable Silicone Facial Brush for 1 minute a day*.
3. **Do not press the brush hard against your skin, as it will reduce the motion and effectiveness. Keep the brush in light contact and flush against the skin.**
4. Move the brush in a slow, circular motion around your face. Let the oscillation do the cleansing. **NOTE: Do not apply treatment close to the eyes to avoid risk of injury.**
5. When finished, rinse with water and dry your skin with a towel.

* The brush will provide up to 120, one-minute uses.

true
glow



BATTERY OPERATED + WATER RESISTANT
mini disposable silicone
facial brush

All Models FCB9
INSTRUCTION GUIDE
CONAIR

MEDIDAS DE SEGURIDAD IMPORTANTES

Al usar aparatos eléctricos, especialmente en presencia de niños, siempre debe tomar precauciones básicas de seguridad, entre ellas las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DE USAR EL CEPILLO FACIAL DE SILICONA DESECHABLE

ADVERTENCIA — Para reducir el riesgo de quemaduras, descarga eléctrica, incendio o heridas:

1. Supervise el uso de este producto cuidadosamente cuando sea usado por, en o cerca de niños o personas con ciertas discapacidades.
2. Use este producto únicamente con el propósito para el cual fue diseñado y solamente según las instrucciones.
3. Mantenga la unidad alejada de superficies calientes.
4. No lo use mientras duerme o si está adormilado/a.
5. No lo use en exteriores, ni lo haga funcionar donde se esté administrando oxígeno.
6. No use este producto si está dañado.

7. Este producto no debe ser usado por niños.
8. Resistente al agua; puede usarse en la ducha, pero no puede ser sumergido en agua.
9. Use este aparato únicamente con el propósito para el cual fue diseñado y solamente según las instrucciones. Solo use accesorios recomendados por Conair.
10. Nunca deje caer ni inserte ningún objeto en ninguna de las aberturas.
11. Los niños o las personas que carezcan de la experiencia o de los conocimientos necesarios para manipular el aparato, o aquellas cuyas capacidades físicas, sensoriales o mentales estén limitadas, no deben usar el aparato sin la supervisión o la dirección de una persona responsable por su seguridad.
12. No permita que los niños jueguen con este aparato.
13. Este producto contiene pilas de botón no reemplazables. No intente abrir la unidad para cambiar las pilas.
14. Este producto contiene dos pilas de botón que pueden causar lesiones graves o la muerte en sólo 2 horas en caso de ingestión. Busque atención médica inmediatamente.

GUARDE ESTAS INSTRUCCIONES

El mini cepillo facial de silicona desechable True Glow® no contiene ninguna pieza que pueda ser reparada/cambiada por el usuario.

INSTRUCCIONES DE MANTENIMIENTO

LIMPIEZA DEL MINI CEPILLO FACIAL DE SILICONA DESECHABLE TRUE GLOW®

1. Después de cada uso, enjuague el cepillo y límpielo con un paño ligeramente humedecido para eliminar los residuos de loción/aceite.
2. Limpie la unidad con un paño humedecido con agua jabonosa tibia una vez por semana para eliminar los residuos de loción/aceite. Séquela con un paño seco y guárdela en su caja o en un lugar limpio y seco.
3. No use limpiadores abrasivos para limpiar la unidad.
4. No meta la unidad al lavavajillas.

ALMACENAJE

Cuando no esté en uso, apague la unidad y guárdela en un lugar seco y seguro, fuera del alcance de los niños.

SENSIBILIDAD Y PRECAUCIONES PRECAUCIONES ESPECIALES ACERCA DE LAS ÁREAS DELICADAS

El mini cepillo facial de silicona desechable True Glow® ha sido diseñado para limpiar la piel del rostro y del cuerpo, dejándola limpia y con una apariencia saludable. El mini cepillo facial de silicona desechable True Glow® no es un aparato médico y no ha sido diseñado para tratar ninguna condición médica, tal como el acné.

Si usted está bajo el cuidado de un médico para cualquier condición dermatológica o si su piel es muy sensible, por favor, consulte con su médico antes de usarlo.

Se desaconseja compartir el cepillo con otra persona; cada usuario debe tener su propio cepillo.

No use el aparato con cremas exfoliantes o productos que contengan partículas ásperas.

Nota: Usar el cepillo para quitarse el maquillaje puede descolorar el cepillo. Sin embargo, esto no afectará su rendimiento.

Interrumpa el uso de este producto y llame a su médico en caso de dolor o incomodidad durante el uso.

Moje su rostro y aplique la cantidad deseada de limpiador facial en la piel. También ponga una pequeña cantidad de limpiador en el cepillo humedecido. No presione el cepillo contra la piel; deje que la oscilación lleve a cabo la limpieza. Después de terminar, enjuague la piel con agua y séquela con una toalla limpia.

CARACTERÍSTICAS DEL MINI CEPILLO FACIAL DE SILICONA DESECHABLE TRUE GLOW®



Botón de encendido/apagado

INSTRUCCIONES DE OPERACIÓN

El mini cepillo facial de silicona desechable True Glow® Funciona con 2 pilas de botón (incluidas).



GARANTÍA LIMITADA DE UN AÑO (VÁLIDA EN LOS EE. UU. Y EN CANADÁ SOLAMENTE)

Conair reparará o reemplazará (a su opción) este producto sin cargo por un periodo de 12 meses a partir de la fecha de compra si presenta defectos de fabricación o materiales.

Para obtener servicio técnico bajo esta garantía, devuelva el producto defectuoso al Centro de Servicio indicado a continuación, junto con su recibo de compra. Los residentes de California solo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el periodo de garantía será de 12 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO, PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 12 MESES DE LA PRESENTE GARANTÍA ESCRITA.

Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA.

Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

CÓMO ENCEDER LA UNIDAD

Presione el botón de encendido/apagado una vez para encender la unidad.

CÓMO APAGAR LA UNIDAD

Presione el botón de encendido/apagado una vez para apagar la unidad.

INSTRUCCIONES DE USO DEL MINI CEPILLO FACIAL DE SILICONA DESECHABLE

1. Moje su rostro y aplique una generosa cantidad de limpiador facial. También ponga una pequeña cantidad de limpiador en el cepillo humedecido.
2. Presione el botón de encendido/apagado una vez para encender la unidad. Recomendamos usar el cepillo facial de silicona desechable durante 1 minuto al día*.
3. **No presione mucho el cepillo contra la piel; esto disminuirá su movimiento y reducirá su eficacia. Mantenga el cepillo contra la piel, sin presionar.**
4. Mueva el cepillo lentamente contra la piel, haciendo pequeños movimientos circulares. Deje que la oscilación lleve a cabo la limpieza. **NOTA: Para evitar el riesgo de heridas, no acerque el cepillo a los ojos.**
5. Después de terminar, enjuague la piel con agua y séquela con una toalla limpia.

*El cepillo proporcionará hasta 120 usos de 1 minuto.

6


Zonas de limpieza FACIAL



NOTA: USE EL CEPILLO POR 10 SEGUNDOS EN CADA ZONA.



LIMPIEZA FACIAL CON UN NUEVO GIRO



A PILAS • RESISTENTE AL AGUA
mini cepillo facial de silicona desechable

Modelos FCB9
(todas las versiones)

MANUAL DE INSTRUCCIONES
CONAIR