



This message about...

GROUND

FAULT

CIRCUIT

INTERRUPTERS

...can save a life!

IF YOU MUST USE YOUR HAIR DRYER IN THE BATHROOM, INSTALL A GFCI* NOW!

Your local electrician can help you decide which type is best for you – a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCIs in the bathrooms, garages, and outdoor outlets of all new homes.

WHY DO YOU NEED A GFCI? Electricity and water don't mix. If your hair dryer falls in water while it's plugged in, the electric shock can kill you... **even if the switch is off.** A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.



A GFCI can save your life! Compared to that, the price is small! Don't wait...install one now!

*A GFCI is a sensitive device that reacts immediately to a small electric current leak by stopping the electricity flow.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING KEEP AWAY FROM WATER

DANGER – Any hair dryer is electrically live even when the switch is off. To reduce the risk of death or injury by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.
6. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
7. Never use while sleeping or drowsy.
8. Never drop or insert any object into any opening or hose.
9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
10. Do not use an extension cord to operate dryer.
11. Do not direct hot air toward eyes or other heat-sensitive areas.
12. Attachments may be hot during use. Allow them to cool before handling.
13. Do not place appliance on any surface while it is operating.
14. While using the appliance, keep your hair out of it. Keep your hair away from the air inlets.
15. Do not use with a voltage converter.
16. This appliance is not a toy. Keep away from children.

SAVE THESE INSTRUCTIONS

1. This appliance should never be left unattended when plugged in.
2. This appliance should not be used by, on, or near children or individuals with certain disabilities.
3. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.

USER MAINTENANCE


Your dryer is virtually maintenance free. No lubrication is needed. For proper operating performance, the dryer must be kept clean. When cleaning is needed, unplug the cord, allow to cool and clean dust and lint from air intake openings with a small brush or the brush attachment of a vacuum cleaner. The outer surface of the dryer should be wiped clean with a cloth only.

Blocked or clogged air intake vents will cause the dryer to overheat. If overheating occurs, an automatic safety device will shut the dryer or the heat off to prevent damage or personal injury. If the unit or the heat cycles off, unplug the cord and allow the dryer to cool for 10 to 15 minutes before restarting. Make sure the air vents are clean.

CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE APPLIANCE.

This appliance is equipped with an Appliance Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water. To make sure the ALCI is functioning properly, perform the following test. The purpose of this test is to allow you to make sure the water sensing system (ALCI) is working.

1. Plug in the appliance and press test button on plug.
2. The appliance will stop working. There will be an audible click and reset button will pop out. This indicates the ALCI is functioning properly.
3. To reset ALCI, unit should be unplugged. Then push reset button in, and reinsert plug into outlet.



4. If ALCI is not functioning properly, return appliance to nearest service center.
5. It is important that if immersion occurs, this unit be brought to a service center. Do not try to reset.
6. Be sure to repeat test every time you use the unit to confirm ALCI is operational. Should the appliance go off and the reset button pop up during use, this could indicate a malfunction in the unit. Remove plug from outlet and

CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the dryer. Damage will occur at the high flex point of entry into the dryer, causing it to rupture and short. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**

If the cord or dryer is damaged or does not operate properly, return it for repair to an authorized Conair service representative only. No repairs should be attempted by the consumer.

STORAGE – Important

When not in use, your dryer should be disconnected, allowed to cool and stored in a safe, dry location, out of reach of children. **Do not wrap line cord around dryer.** Allow the cord to hang or lie loose and straight at the point of entry into the dryer.

LIMITED TWO-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 24 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back, together with your purchase receipt and \$5.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 24 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 24-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

allow the appliance to cool. Reinsert plug into outlet. The appliance should then function normally. If not, return it to a Conair Service Center for examination and repair.

SUPER STYLING GUIDE

Your best looks begin with a good haircut that's well maintained. Always treat hair right with superior quality shampoos, conditioners, and finishing products.

BRUSH/COMB ATTACHMENT STYLING BASICS & INSTRUCTIONS

Shampoo and condition hair with products of your choice. Gently towel-dry hair to remove excess moisture. Part hair into sections. Follow the instructions to achieve your desired style. NOTE: To prevent overdrying, reduce setting to LOW when hair is almost dry.

FOR STRAIGHTENING OR RELAXING

Select the brush attachment and set dryer on HIGH speed. Hold dryer securely in one hand and use brush to firmly grasp a section of hair at roots. Roll hair around brush with one turn of your wrist, then pull downward. Continue process until hair is dry. Repeat the above with each hair section.

DUAL ROW STRAIGHTENING COMB

Attach to dryer and select HIGH speed. Slowly drag attachment down hair strand to smooth away frizz and straighten hair. The slower you pass dryer through the strand, the straighter the result.

FOR EXTRA VOLUME AND DETANGLING

Select the detangling comb attachment and set dryer on LOW speed. Hold dryer securely in one hand and use a natural combing action to fluff hair, beginning at the roots. Move from section to section until hair is dry.

Styler/Dryer is perfect for shorter hairstyles on men and women.

FOR CREATING FULLNESS

Select the brush attachment and set dryer on HIGH speed. Starting at the nape of the neck, first lift hair up and away from the scalp with the brush, then rotate the brush downward to the ends. Move from section to section until hair is dry.

GETTING TO KNOW YOUR STYLER/DRYER

The Infiniti PRO by Conair® 3-in-1 Styler is very effective, even at lower temperatures, and helps you get healthy-looking, shiny, more manageable hair with maximum styling control. Your new, professional Infiniti PRO by Conair® styler features a unique release lock button mechanism for easy mounting and secure fastening of attachments. Simply press button to release attachment from barrel.

TOURMALINE CERAMIC HEAT TECHNOLOGY

will keep your hair looking healthy and shiny. It generates full-spectrum infrared heat and ions which work on hair molecules to dry them inside and out. This drying process is gentle and quick; it minimizes heat damage and makes hair less frizzy and more manageable. Tourmaline crystals generate ions that smooth the cuticle for silky, shiny hair.

THE IONIZING FUNCTION generates a cloud of negative ions that can:


- help reduce frizz by up to 75%*
- neutralize the generally positive charge on flyaway, frizzy hair
- eliminate static electricity
- contribute to shine
- make hair less frizzy and more manageable

Use the dryer in the HIGH setting to activate the ionizing function.

**When compared to hair dryers with natural ion generation*

GETTING TO KNOW YOUR STYLER/DRYER

When used without attachments, it's a powerful compact dryer. When used with attachments, it's a versatile hair drying and styling system.



INFINITI PRO
BY CONAIR

1875 WATT 3-IN-1 STYLER



INSTRUCTION & STYLING GUIDE

SD9 MODELS

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Please register this product at www.conair.com/registration

Service Center
Conair Corporation
Service Department
7475 N. Glen Harbor Blvd.
Glendale, AZ 85307

©2017 CONAIR CORPORATION
For info on any Conair or InfinitiPRO by Conair® product, call 1-800-3-CONAIR or visit us on the web at www.conair.com/infiniti
17PD030296

IB-15251

ATTACHMENT ORDER FORM

Replacement attachments for your Infiniti PRO by Conair® 3-in-1 Styler are available by using the form below.

Please make check or money order (no cash or stamps) payable to:

Conair Corporation
150 Milford Road
East Windsor, NJ 08520

Allow four (4) weeks for delivery.
Infiniti PRO by Conair® 3-in-1 Styler
Model #SD9

Attachments	QTY.	TOTAL
Detangling Comb @ \$3.50		
Bristle Styling Brush @ \$4.00		
Dual Row Straightening Comb @ \$4.00		

Send attachments to (please print):

Name: _____

Address: _____

City: _____

State: _____ ZIP: _____

Prices subject to change without notice.



Este mensaje sobre los...

GROUND
FAULT
CIRCUIT
INTERRUPTERS

(Interruptores de circuito de

falla a tierra)

...puede salvar una vida.

¡SI DEBE USAR EL SECADOR EN EL CUARTO DE BAÑO, INSTALE UN INTERRUPTOR DE CIRCUITO DE FALLA A TIERRA* AHORA!

Su electricista le puede ayudar a decidir cuál sistema escoger – un sistema removible que se conecta a la toma de corriente o un sistema permanente que él instalará. El Código Nacional de Electricidad ahora exige que todos los enchufes ubicados en los cuartos de baño, los garajes y las partes exteriores de las casas nuevas sean equipados con un interruptor de control de potencia (GFCI, por sus siglas en inglés).



¿POR QUÉ NECESITA UN INTERRUPTOR DE CIRCUITO DE FALLA A TIERRA? La electricidad y el agua no deben juntarse. Si el aparato se cae al agua mientras está conectado, una descarga eléctrica puede causar su muerte... **aunque el interruptor esté en la posición de apagado.** Un fusible o un disyuntor/interruptor de circuito regular no le protegerán en esta situación. Un interruptor de circuito de falla a tierra ofrece más protección.

¡Un interruptor de circuito de falla a tierra puede salvar su vida! ¡Comparado con ella, el precio es bajo! ¡No espere... instale uno ahora mismo!

*Un interruptor de circuito de falla a tierr (GFCI por sus siglas en inglés) es un dispositivo sensible que reacciona inmediatamente a una pequeña pérdida de corriente, deteniendo el flujo de electricidad.

INSTRUCCIONES DE MANTENIMIENTO

Su secador requiere poco mantenimiento. No necesita lubricación. Para que funcione correctamente, debe mantenerlo limpio. Cuando sea necesario limpiarlo, desconéctelo, permita que se enfríe y quite el polvo y las pelusas de las aberturas de aire con un cepillo pequeño o el cepillo accesorio de una aspiradora. L superficie exterior del secador solo se debe limpiar con un paño limpio.

El secador se recalentará si las aberturas de aire están bloqueadas u obstruidas. Si esto ocurriera, un sistema de seguridad apagará el secador o cortará la temperatura automáticamente para evitar daños al aparato o lesiones personales. Si esto sucediera desenchufe el aparato y permita que se enfríe por 10 a 15 minutos antes de encenderlo de nuevo. Asegúrese de que las ventilaciones de aire están limpias.

PRECAUCIÓN

NUNCA jale, retuerza ni doble mucho el cable. Nunca lo enrolle con fuerza alrededor del aparato; esto puede dañar la junta flexible que lo conecta al aparato, produciendo su ruptura o un cortocircuito. Revise el cable con frecuencia para asegurarse de que no está dañado. **Deje de usar el aparato inmediatamente si el cable está visiblemente dañado, o si el aparato deja de funcionar o funciona de manera intermitente.**

Si el cable o el aparato están dañados o si el aparato no funciona correctamente, regréselo a un centro de servicio autorizado. No trate de reparar este aparato.

ALMACENAJE – Importante Después de usar el aparato, desconéctelo, permita que se enfríe y guárdelo en un lugar seco y seguro, fuera del alcance de los niños. **No enrolle el cable alrededor del aparato.** Permita que el cable cuelgue o que la junta que lo conecta al aparato esté suelta y recta.

GARANTÍA LIMITADA DE DOS AÑOS (VÁLIDA EN LOS EE.UU. Y EN CANADÁ SOLAMENTE)

Conair reparará o reemplazará (a su opción) su aparato sin cargo por un período de 24 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regrese su aparato al Centro de Servicio indicado al dorso, junto con su recibo de compra y un cheque o giro postal de US\$5.00 para cubrir los gastos de manejo y envío. Los residentes de California solo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 24 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 24 MESES DE LA PRESENTE GARANTÍA ESCRITA. Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA. Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted. Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

la raíz con el cepillo. Enrolle el cabello alrededor del cepillo con un giro de la muñeca, y luego jale hacia abajo. Continúe el proceso hasta que el cabello esté seco. Repita el proceso en cada sección.

PEINE ALISADOR CON DOS FILAS DE DIENTES Instale el accesorio sobre el secador. Elija el ajuste de temperatura/velocidad alto (HIGH). Alise el cabello lentamente, desde la raíz hasta las puntas. Cuanto más lento el alisado, mejor el resultado.

PARA AGREGAR VOLUMEN Y DESENREDAR Instale el peine para desenredar sobre el secador. Elija el ajuste de temperatura/ velocidad bajo (LOW). Sosteniendo firmemente el secador en una mano, peine el cabello, empezando en la raíz, para darle volumen. Repita el proceso en cada sección, hasta que el cabello esté seco.

Este secador es perfecto para los estilos cortos, tanto para mujeres como para hombres.

PARA DAR CUERPO

Instale el cepillo sobre el secador. Elija el ajuste de temperatura/velocidad alto (HIGH). Empezando en la nuca, agarre el cabello con el cepillo y álcelo lejos de la cabeza; luego gire el cepillo hacia abajo y desícelo hasta las puntas. Repita el proceso en cada sección, hasta que el cabello esté seco.

FAMILIARÍCESE CON SU SECADOR

El secador 3 en 1 Infiniti PRO by Conair® seca el cabello de manera muy eficaz, incluso con calor bajo. Ayudará a mantener su cabello saludable, brillante y dócil mientras brindará máximo control durante el peinado.

Su nuevo secador multiuso profesional Infiniti PRO by Conair® cuenta con un mecanismo exclusivo de bloqueo/liberación de los accesorios que permite instalar y retirar estos fácilmente. Simplemente oprima el botón para liberar el accesorio.

TECNOLOGÍA CERÁMICA CON TURMALINA La tecnología cerámica con turmalina ayudará a mantener su cabello brillante y saludable. Genera calor infrarrojo de amplio espectro e iones negativos, los cuales actúan al nivel molecular para secar el cabello desde el interior. Este método de secado suave y rápido minimiza los daños causados por el calor, reduce el frizz y deja el cabello más dócil. Los cristales de turmalina generan iones que suavizan la cutícula y dejan el cabello brillante y sedoso.

LA FUNCIÓN IÓNICA genera una nube de iones negativos que pueden:

- ayudar reducir el frizz hasta en un 75 %*
- neutralizar la carga positiva en el cabello con frizz
- eliminar la estática
- agregar brll
- reducir el frizz y facilitar el peinad

Nota: utilice el ajuste de temperatura/velocidad alto para activar la función iónica

**En comparación con los secadores con fuente natural de iones*



FAMILIARÍCESE CON SU SECADOR MULTIFUNCIÓN

Sin sus accesorios, es un potente secador compacto. Con sus accesorios, es una herramienta versátil que seca y peina.

FORMULARIO DE PEDIDO – ACCESORIOS DE REPUESTO

Utilice el formulario a continuación para pedir accesorios de repuesto para su secador 3 en 1 InfinitiPRO by Conair®.

Favor de incluir un cheque o giro postal (sentimos no poder aceptar dinero en efectivo ni estampillas) a nombre de:

Conair Corporation
150 Milford Road
East Windsor, NJ 08520

La entrega demora 4 semanas. Secador 3 en 1 InfinitiPro By Conair® Modelo SD9

Accesorio	CANTIDAD	TOTAL
Peine para desenredar \$3.50		
Cepillo de cerdas \$4.00		
Peine alisador con dos filas de dientes \$4.00		

Envíe los accesorios a (favor de escribir en letra de molde):

Nombre: _____

Dirección: _____

Ciudad: _____

Estado: _____ **Código postal:** _____

los precios están sujetos a cambio sin previo aviso.