



Protective Door Press Pad Use Guide

INSTRUCTIONS FOR USE:

- 1 Set up your Conair® garment steamer.
- 2 Attach the door press pad by placing the elastic straps over the top corners of your door and allowing the pad to hang down over your door with silver side facing you.
- 3 Place your garment on a hanger and hang from the center hook.
- 4 Pass the steam jets just above the wrinkled fabric. It may take a few passes to remove the wrinkles completely.
- 5 For heavier fabrics or severely wrinkled fabrics, take slower passes.
- 6 Always keep the unit in motion. Do not continuously hold steamer over an area to be treated, as damage may occur.

make your life
A LITTLE SMOOTHER®

Note: Some assembly required.

- This garment steaming door press pad is for use with all Conair® garment steamers. Not meant for use with irons.
- To assemble your door press pad, insert bars into the top of the door pad. With the hanger folded, slide each end of the rod into the fabric opening on the door pad.
- With both hands, carefully open the hanger until you hear a snap, keeping the plastic hook in front of the door pad
- Attach adjustable straps to your door.
- Place your garment on a hanger and hang from the hook in the center.

WARNING:

1. Use caution when using this pad with your garment steamer, as surface may get hot. Hot steam can cause burns!
2. When using over a door, do not allow the steam from your Conair garment steamer to reach outside of the press pad area as damage may occur.
3. Surfaces of a garment steamer are hot when in use. Do not let heated surfaces touch eyes or skin.
4. Do not hold hand in front of or behind steam.
5. Do not place the garment steamer's steam nozzle directly on any surface.
6. Burns could occur from touching hot parts, hot water, or steam from a garment steamer. Always position steamer with the head away from you and any other person when turning on.
7. When emitting steam, a garment steamer may cause burns if it is used too close to the skin or eyes, or if it is used incorrectly. To reduce the risk of contact with hot water emitting from the steam vents, test appliance before use by holding it away from the body.




For information on any Conair product, call 1-800-3-CONAIR or visit us on the web at www.conair.com




Protective Door Press Pad Use Guide



1. With the hanger folded, slide each end of the rod into the fabric opening on the door pad



2. With both hands, carefully open the hanger until you hear it snap, keeping the plastic hook in front of the door pad



3. Attach adjustable straps to the door.



4. Hang garment from hook. Happy steaming!