

# IMPORTANT SAFETY INSTRUCTIONS

WHEN USING AN ELECTRICAL FURNISHING, ESPECIALLY WHEN CHILDREN ARE PRESENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE TAKEN, INCLUDING THE FOLLOWING:

## READ ALL INSTRUCTIONS BEFORE USING THIS FURNISHING

**DANGER** — TO REDUCE THE RISK OF ELECTRIC SHOCK: ALWAYS UNPLUG THIS FURNISHING FROM THE ELECTRICAL OUTLET BEFORE CLEANING OR SERVICES AFTER CLEANING.

**WARNING** — TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS:

1. Unplug from outlet before putting on or taking off parts.
2. Close supervision is necessary when this furnishing is used by or near children, invalids, or disabled persons.
3. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
4. Never operate this furnishing if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water. Return the furnishing to a service center for examination and repair.
5. Keep the cord away from heated surfaces.
6. Never drop or insert any object into any opening.
7. Do not use outdoors.
8. Do not operate where aerosol (spray) products are being used or where oxygen is being administered.

9. Never operate the furnishing with the air openings blocked. Keep the air openings free of lint, hair and the like.
10. To protect against electrical hazards, do not use while bathing or in the shower.

11. **Be sure mirror is not in a position where it can reflect sunlight; reflected sunlight can cause a fire.**

12. Do not use on a soft surface such as a bed or couch, where openings may be blocked.
13. Select the OFF setting, allow the unit to cool and unplug cord before storage or cleaning.
14. Do not place or store this furnishing where it can fall or be pulled into a tub or sink.
15. If this furnishing falls into water, unplug it immediately. **Do not reach into the water.**
16. Never use while sleeping or drowsy.
17. Do not leave appliance unattended when it is plugged in.
18. This appliance is not a toy. Keep away from children.
19. To disconnect, turn all controls to the OFF position, then remove plug from outlet.
20. Use on any 120V / 60Hz AC electrical outlet only. Do not use on any other electrical outlets.

### FOR HOUSEHOLD USE ONLY

## SAVE THESE INSTRUCTIONS

**CAUTION:** TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT OF OUTLET AND FULLY INSERT.

**CAUTION:** DISCONNECT FROM THE SUPPLY CIRCUIT BEFORE SERVICING OR CLEANING.

**CAUTION:** PRODUCT HAS NO USER SERVICABLE PARTS INSIDE AND THE COMPANY SHOULD BE CONTACTED FOR SERVICE.

**DO NOT SUBMERSE.**  
**RATING:** 120V AC 60Hz 0.1A 6W

## OPERATING INSTRUCTIONS

**CAUTION:** BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE.


To reduce the risk of electric shock, this lighted mirror has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Never use with an extension cord unless plug can be fully inserted. Do not change the plug in any way.

1. The mirror is touch activated. Touch the mirror to turn ON/OFF, change light settings to LOW, MEDIUM, HIGH and change light modes to OFFICE, HOME, DAY.
2. Your lighted mirror has a 1x magnification and a 10x spot magnification.
3. After use, touch the settings to OFF.
4. The beauty and design of this mirror complements any décor. Therefore, you may wish to leave the mirror displayed. However, if you choose to store the mirror, see STORAGE section in this manual.
5. This is a 2-in-1 cord/cordless handheld mirror so you can use the lighting with or without the charging base.
6. The innovative handheld feature allows you to hold the mirror anywhere and everywhere.

7. Before hand-held use, the mirror needs to be fully charged for about 3 hours. The charging indicator light will be red while charging and then turn green once the mirror is fully charged. Mirror will stay lit for approximately 1 hour before recharging is necessary.
8. To preserve the rechargeable battery and maintain its optimum capacity, it should be charged for 3 hours every 3 months.




Lifetime LED Lighting



1x Magnification



3 light Settings:  
LOW, MEDIUM,  
HIGH



10x Spot  
Magnification



3 Light Modes  
OFFICE, HOME, DAY

### BATTERY REMOVAL



RBRC™ is a trademark of the Rechargeable Battery Recycling Corporation.

The battery is sealed inside the mirror, so it cannot be easily removed for recycling. The entire mirror should be returned when recycling the battery for this product.

**NOTE:** Contains 1 lithium ion battery. Airline restrictions may apply. Check with your carrier.

**CONTAINS LITHIUM ION BATTERY. MUST BE COLLECTED, RECYCLED OR DISPOSED OF PROPERLY. DO NOT DISPOSE OF IN THE MUNICIPAL WASTE. KEEP AWAY FROM WATER.**

### STORAGE

Disconnect device from electrical outlet. BE SURE DIRECT SUNLIGHT DOES NOT STRIKE MIRROR WHEN LEFT UNATTENDED; REFLECTED SUNLIGHT CAN CAUSE FIRE. Allow to cool to room temperature before storing. Place in a cool, dry area out of reach of children, where it will not be damaged.

### MAINTENANCE

Your lighted mirror is designed for household use only and is virtually maintenance free. No lubrication is needed.

If cleaning becomes necessary, disconnect the appliance from the power source and wipe exterior with a cloth. Clean mirror surfaces with a glass cleaner. Do not turn on light until you are certain mirror is completely dry to protect against electrical hazards.

If any abnormal condition occurs, unplug the lighted mirror, allow it to cool, and return it to an authorized service center for repair.

Handle cord carefully for longer life; do not jerk or strain at plug connections, or wrap cord around mirror for storage. This could cause damage to the cord and the mirror could short-circuit. To store mirror, coil cord loosely.

**WARNING:  
IF YOU THINK  
THE POWER IS  
OFF WHEN THE  
SWITCH IS OFF,  
YOU'RE WRONG.**

### KEEP AWAY FROM WATER



Everybody knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

### ALWAYS UNPLUG SMALL APPLIANCES

### BATTERY SAFETY INFORMATION

1. This product requires a lithium ion battery (included).
2. Since batteries are sensitive to high temperatures, when storing them, keep them in a cool, dry place.
3. Battery contacts need to be clean, both on the battery and in the appliance, before installation.
4. Batteries should be removed from appliance when not being used for long periods of time (months).
5. Never recharge non-rechargeable batteries.
6. Use only the power cord supplied with the appliance.
7. Be careful and install (+) and (-) to the correct plus and minus on device.
8. Replace all old batteries at one time. Do not mix old and new.
9. Remove discarded batteries immediately to avoid leakage.
10. Never put batteries into a fire.
11. Switch off devices after use.
12. Keep batteries away from children, especially the batteries that are small enough to ingest.
13. If a battery is ingested, seek immediate medical help.
14. Never open, crush, puncture or disassemble batteries.
15. Dispose of batteries according to any state and local regulations.
16. Do not dispose of rechargeable batteries as a solid waste.

### FEDERAL COMMUNICATIONS COMMISSION NOTICE

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### SUPPLIER'S DECLARATION OF CONFORMITY

**Brand:** Conair®  
**Model No.:** BE123HH  
**Description:** Hand-Held Mirror  
**Responsible Party:** Conair LLC,  
1 Cummings Point Road, Stamford, CT 06902  
(203) 351-9000  
**Standards:** FCC Part 15 Subpart B, ANSI C63.4-2014

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**DATE OF ISSUE:** XX/XX/XXXX

### LIMITED ONE-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed below, together with your purchase receipt. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

For info on any Conair product, call 1-800-3-CONAIR or visit us on the web at [www.conair.com](http://www.conair.com)

**Please register this product at [register.conair.com](http://register.conair.com)**

**Service Center**  
Conair LLC  
Service Department  
7475 North Glen Harbor Blvd.  
Glendale, AZ 85307

©2022 Conair LLC

22PM083304

IB-17636

**HALO**  
It's all about the effect



### instruction guide

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.  
**Model BE123HH**

