

USER MAINTENANCE INSTRUCTIONS

CARING FOR YOUR TRUE GLOW® 3-IN-1 FACIAL CLEANSING SYSTEM

1. After each use, rinse brush head and wipe the brush handle with a damp cloth to remove any oils or lotions used during treatment.
2. Clean unit thoroughly each week by rinsing under warm, soapy water to help remove oil and lotion buildup, wipe with a dry cloth and store unit in its box or in a clean, dry place.
3. Remove brush heads once a week and rinse under warm, soapy water to remove residue accumulated during treatment. Allow brush heads to air-dry. Store in a clean, dry place.
4. Do not use abrasive cleaners for cleaning.
5. Do not put unit in dishwasher for cleaning.
6. When storing the brush off the unit, use the protective cover. This will prevent the bristles from deforming.

NOTE: It is recommended to replace the brush attachments every 90 days, as the bristles wear over time and lose their efficacy.

TROUBLE-SHOOTING GUIDE

THE BRUSH IS NOT WORKING.	<ol style="list-style-type: none"> 1. Make sure the contacts in the unit are clean. See user maintenance instructions for cleaning procedure. 2. Make sure the batteries are installed properly.
THE BRUSH OPERATES AT SLOW SPEED.	Replace the batteries.
THE BRUSH HEAD VIBRATES OR FALLS OFF DURING USE.	<ol style="list-style-type: none"> 1. Make sure the brush head is snapped on properly. 2. Replace the brush head.

1. Always purchase the correct size and grade of battery most suitable for the intended use.
2. Replace all batteries of a set at the same time.
3. Clean the battery contacts and also those of the device prior to battery installation.
4. Ensure the batteries are installed correctly with regard to polarity (+ and -).
5. Remove batteries from equipment that is not to be used for an extended period of time.
6. Remove used batteries promptly.
7. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.

LIMITED ONE-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed on back that is nearest you, together with your purchase receipt and \$3.00 for postage and handling. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING THE 3-IN-1 FACIAL CLEANSING SYSTEM

1. Close supervision is required when this product is used on, by or near children or people with certain disabilities.
2. Use product only for its intended use as described in this instruction booklet. Do not use attachments not recommended by the manufacturer.
3. Keep the unit away from heated surfaces.
4. Never use while sleeping or drowsy.
5. Do not use outdoors or where oxygen is being administered.
6. Never operate if the product is damaged.
7. Not for use by children.
8. Water resistant: Can be rinsed in a shower but not submerged.

The True Glow® 3-in-1 Facial Cleansing System handle has no serviceable parts. Call 1-800-3-CONAIR for instructions to purchase replacement brush heads.

SENSITIVITY AND CAUTIONS SPECIAL CAUTIONS FOR DELICATE AREAS

The True Glow® 3-in-1 Facial Cleansing System is a face and body cleansing device that is intended to help you get clean and healthy-looking skin. The True Glow® 3-in-1 Facial Cleansing System is not a medical device and is not intended to be used to treat any medical conditions such as acne.

If you are under a doctor's care for any skin condition or if you think you have very sensitive skin, please consult your physician before use.

We recommend not sharing the brush heads; each user should have their own brush head.


Do not use with exfoliation creams with rough or jagged particles.

Removing makeup can cause the brush head to discolor. This will not affect performance and the brush head can be used for the entire recommended life of 90 days.

If you experience any pain or discomfort during use, stop using and consult your physician.

Moisten your face and apply cleanser. Also apply a small amount of cleanser to the moistened brush head. Do not apply pressure with the brush to the face; let the oscillation perform the cleansing. When finished, rinse with water and dry skin with a clean towel.

TRUE GLOW® 3-IN-1 FACIAL CLEANSING SYSTEM FEATURES



FACIAL CLEANSING BRUSH

ENHANCED EYE MASSAGER

ONE SPEED

BATTERY COVER

ATTACHMENTS

CLEANSING BRUSH: For cleansing, gentle exfoliation, moisturizing and massaging.

MAKEUP BRUSH: Perfect for applying your favorite foundation or powder to the entire face.

ENHANCED EYE MASSAGER: Gently massages under eyes, leaving skin feeling bright and smooth.

NOTE: Your True Glow® 3-in-1 Facial Cleansing System may only include certain attachments. See retailer for replacement units or call 1-800-3-CONAIR or visit www.trueglowbyconair.com



CLEANSING BRUSH

MAKEUP BRUSH



ENHANCED EYE MASSAGER

OPERATING INSTRUCTIONS

NOTE: The True Glow® 3-in-1 Facial Cleansing System operates on 1 AAA battery (not included).

1. Remove the battery cover until the battery door is released.
2. Install 1 AAA battery (not included) as per the markings in the battery compartment.
3. Replace the cover until the battery door is firmly closed.
4. Select cleansing brush attachment and push it down onto the mounting post until firmly in place.



STARTING THE 3-IN-1 FACIAL CLEANSING SYSTEM

Press the ON/OFF button one time to turn on the 3-in-1 Facial Cleansing System.

STOPPING THE 3-IN-1 FACIAL CLEANSING SYSTEM

Press ON/OFF button two times to stop the unit.

ATTACHING AND REMOVING ATTACHMENTS

To attach, hold the brush by the rim and attach over mounting post until it firmly snaps into place. To remove, hold the rim and pull off.



NOTE: USE FOR 10 SECONDS AT EACH LOCATION

INSTRUCTIONS FOR USING THE 3-IN-1 FACIAL CLEANSING SYSTEM

1. Wet your face and apply sufficient cleanser. Also apply a small amount of cleanser to the wet brush head.
2. Select attachment and attach to power handle.
3. Press the ON/OFF button one time to start 3-in-1 Facial Cleansing System.
4. Do not press the brush hard against your skin, as it will reduce the motion and effectiveness. Keep the brush in light contact and flush against the skin.

true glow®

Skincare Beauty Essentials for professional results



CONAIR
Model FBEMRG

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.

Please register this product at www.conair.com/registration

SERVICE CENTERS CONAIR CORPORATION

Service Department
150 Milford Road
East Windsor, NJ 08520

CONAIR CORPORATION

Service Department
7475 North Glen Harbor Blvd.
Glendale, AZ 85307

Visit us on the web at www.conair.com

©2017 Conair Corporation
East Windsor, NJ 08520
Glendale, AZ 85307

17PS030678

IB-15291

INSTRUCTIONS FOR USING THE EYE MASSAGER

5. Move the brush in a slow, circular motion around your face. Let the oscillation do the cleansing. **NOTE: Do not apply treatment close to the eyes to avoid risk of injury.**

6. When finished, rinse with water and dry your skin with a towel.

6. When finished, rinse with water and dry your skin with a towel.

6. When finished, rinse with water and dry your skin with a towel.

6. When finished, rinse with water and dry your skin with a towel.

6. When finished, rinse with water and dry your skin with a towel.

6. When finished, rinse with water and dry your skin with a towel.

INSTRUCTIONS FOR USING THE MAKEUP BRUSH

1. Select attachment and attach to power handle.
2. Apply foundation to the middle of the makeup brush.
3. Press the ON/OFF button once to start the gentle vibration, allowing you to blend your makeup quicker for photo-finish results.

4. Do not press the brush hard against your skin, as it will reduce the motion and effectiveness. Keep the brush in light contact and flush against the skin.

5. Start applying foundation to your face with short, downward strokes, blending properly.

NOTE: Do not apply foundation close to the eyes to avoid risk of injury.

INSTRUCCIONES DE MANTENIMIENTO

LIMPIEZA DEL SISTEMA DE LIMPIEZA FACIAL 3 EN 1 TRUE GLOW®

- Después de cada uso, enjuague el cabezal y limpie el mango del cepillo con un paño ligeramente humedecido para eliminar los residuos de loción/aceite.
- Limpie la unidad con un paño humedecido con agua jabonosa tibia una vez por semana para eliminar los residuos de loción/aceite. Séquela con un paño seco y guárdela en su caja o en un lugar limpio y seco.
- Una vez por semana, retire el cabezal y lávelo en agua jabonosa tibia para eliminar los residuos acumulados durante el tratamiento. Permita que las piezas se sequen al aire. Guarde el aparato en un lugar limpio y seco.
- No utilice limpiadores abrasivos para limpiar la unidad.
- No meta la unidad al lavavajillas.
- Regrese la cubierta protectora sobre el cepillo antes de guardarlo; esto evitará que las cerdas se deformen.

NOTA: se recomienda cambiar los accesorios cada 3 meses, ya que las cerdas se desgastan con el paso del tiempo, perdiendo su eficacia.

RESOLUCIÓN DE PROBLEMAS

EL CEPILLO NO FUNCIONA.	<ol style="list-style-type: none">Asegúrese de que los contactos de las pilas estén limpios. Véase las instrucciones de mantenimiento/limpieza.Cerciórese de que las pilas están debidamente instaladas.
EL CEPILLO SÓLO FUNCIONA A VELOCIDAD BAJA.	Cambie las pilas.
EL CABEZAL VIBRA O SE CAE DURANTE EL USO.	<ol style="list-style-type: none">Asegúrese de que el cabezal esté debidamente instalado.Cambie el cabezal.

- No utilice pilas que no sean del tamaño ni de la potencia indicados para uso con este aparato.
- Cambie todas las pilas al mismo tiempo.
- Limpie los contactos del aparato y los de la(s) pila(s) antes de instalar esta(s).
- Siempre respete los signos de polaridad (+/-) al instalar las pilas.
- Retire la(s) pila(s) si no va a usar el aparato por un largo período de tiempo.
- Retire las pilas gastadas lo antes posible.
- No junte pilas nuevas con pilas usadas. No junte pilas alcalinas con pilas regulares (carbono-zinc) o pilas/baterías recargables.

GARANTÍA LIMITADA DE UN AÑO (VÁLIDA EN LOS EE.UU. Y EN CANADÁ SOLAMENTE)

Conair reparará o reemplazará (a su opción) su aparato sin cargo por un período de 12 meses a partir de la fecha de compra si presentara defectos de materiales o fabricación.

Para obtener servicio técnico bajo esta garantía, regrese su aparato al Centro de Servicio indicado a continuación, junto con su recibo de compra y un cheque o giro postal de US\$3.00 para cubrir los gastos de manejo y envío. Los residentes de California solo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 12 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 12 MESES DE LA PRESENTE GARANTÍA ESCRITA.

Algunos Estados no permiten limitaciones sobre la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA.

Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

CARACTERÍSTICAS DEL SISTEMA DE LIMPIEZA FACIAL 3



ACCESORIOS

CEPILLO DE LIMPIEZA:

Limpia, exfolia, hidrata y masajea suavemente.

CEPILLO DE MAQUILLAJE:

Perfecto para aplicar su base favorita o polvo en el rostro entero.

MASAJEADOR DE OJOS ANTIBOLSAS:

Masajea suavemente el área debajo de los ojos, dejando la piel tersa y luminosa.

NOTA: puede que su sistema de limpieza facial 3 en 1 True Glow® no incluya todos los accesorios disponibles. Para conseguir piezas adicionales o de repuesto, comuníquese con su detallista, llame al 1-800-3-CONAIR o visite www.trueglowbyconair.com



CEPILLO DE LIMPIEZA



CEPILLO DE MAQUILLAJE



MASAJEADOR DE OJOS ANTIBOLSAS

INSTRUCCIONES DE OPERACIÓN

NOTA: el sistema de limpieza facial 3 en 1 True Glow® requiere 1 pila AAA (no incluida).

- Abra el compartimiento de la pila.
- Instale 1 pila AAA (no incluida) en el compartimiento, respetando los signos de polaridad +/-.
- Cierre el compartimiento de la pila.
- Instale el cepillo de limpieza, presionando firmemente para sujetarlo.



CÓMO ENCENDERLA UNIDAD

Presione el botón de encendido/apagado una vez.

CÓMO APAGAR LA UNIDAD

Presione el botón de encendido/apagado dos veces.

INSTALACIÓN/REMOCIÓN DE LOS ACCESORIOS

Para instalar el cepillo, sosténgalo por la orilla e insértelo sobre el cabezal, presionando hasta que haga clic. Para retirarlo, sosténgalo por la orilla y júelo hacia arriba.

true glow®

Productos esenciales de cuidado de la piel para resultados profesionales



CONAIR®

Modelo FBEMRG

Para su seguridad y para disfrutar plenamente de este producto, siempre lea cuidadosamente las instrucciones antes de usarlo.

17PS030678

IB-15291



NOTA: USE EL CEPILLO DURANTE 10 SEGUNDOS EN CADA ZONA.

MODO DE EMPLEO DEL SISTEMA DE LIMPIEZA FACIAL 3 EN 1

- Moje su rostro y aplique una generosa cantidad de limpiador facial. También moje el cabezal y ponga una pequeña cantidad de limpiador sobre este.
- Instale el accesorio deseado sobre el mango.
- Presione el botón de encendido/apagado una vez para encender la unidad.
- No presione el cepillo contra la piel; esto disminuirá el movimiento del cepillo y reducirá la eficacia de la limpieza. Mantenga el cepillo contra la piel, sin presionar.**
- Mueva el cepillo lentamente contra la piel, haciendo pequeños movimientos circulares. Deje que la oscilación lleve a cabo la limpieza. **NOTA: no acerque el cepillo a los ojos; esto puede causar heridas.**

- Después de terminar, enjuague la piel con agua y séquela con una toalla limpia.

MODO DE EMPLEO DEL MASAJEADOR DE OJOS ANTIBOLSAS

- Quite el cepillo de limpieza facial, jalando suavemente.
- Aplique los sérums de su elección.
- Presione el botón de encendido/apagado una vez para encender la unidad.
- No presione el masajeador contra la piel; esto disminuirá el movimiento del masajeador y reducirá la eficacia del masaje. Mantenga el masajeador contra la piel, sin presionar.**
- Mueva el masajeador lentamente contra la piel, haciendo pequeños movimientos circulares alrededor de los ojos. Deje que la vibración lleve a cabo el masaje. **NOTA: no acerque la punta del masajeador a los ojos.**
- Después de terminar, enjuague la piel con agua y séquela con una toalla limpia.

MODO DE EMPLEO DEL CEPILLO DE MAQUILLAJE

- Instale el cepillo de maquillaje sobre el mango.
- Aplique una pequeña cantidad de base en el centro del cepillo.
- No presione el cepillo contra la piel; esto disminuirá el movimiento del cepillo y reducirá la eficacia de la limpieza. Mantenga el cepillo contra la piel, sin presionar.**
- Empiece a aplicar la base en el rostro, usando pequeños movimientos hacia abajo para fundir la base. **NOTA: no aplique base muy cerca de los ojos; esto puede causar heridas.**
- Presione el botón de encendido/apagado una vez para poner en marcha las vibraciones suaves, las cuales le permitirán fundir la base para conseguir un acabado perfecto.