

LIMITED ONE-YEAR WARRANTY (U.S. ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.

Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

READ ALL INSTRUCTIONS BEFORE USING

KEEP AWAY FROM WATER

DANGER — To reduce the risk of electrocution:


1. Do not place or store appliance where it can fall or be pulled into a tub or sink.
2. Do not place in, or drop into water or other liquids.
3. **Do not reach for an appliance that has fallen into water or other liquids. Unplug immediately.**

WARNING — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
2. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
3. This appliance is intended to be used in household.

**WARNING:
IF YOU THINK THE
POWER IS OFF
WHEN THE SWITCH
IS OFF,
YOU'RE WRONG.**

KEEP AWAY FROM WATER



Everyone knows that electricity and water are a dangerous combination. But did you know that an electrical appliance is still electrically live even if the switch is off? If the plug is in, the power is on. So when you are not using your appliances, keep them unplugged.

ALWAYS UNPLUG SMALL APPLIANCES

FEDERAL COMMUNICATIONS COMMISSION NOTICE

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications not expressly approved by Conair Corporation, the manufacturer of this product and the party responsible for compliance, could void the user's authority to operate the equipment.

SUPPLIER'S DECLARATION OF CONFORMITY

Brand: CONAIR®

Model No.: SKIN1

Description: Beauty Skincare Fridge

Responsible Party: Conair LLC

1 Cummings Point Road, Stamford, CT 06902

(203) 351-9000

Standards: FCC Part 15 Subpart B, ANSI C63.4-2014

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesirable operation.

DATE OF ISSUE: X/XX/XXXX

Due to continuing product improvements, the actual product purchased may differ slightly from the one shown.

Please register this product at www.conair.com/registration

SERVICE CENTER

CONAIR LLC

Service Department
7475 North Glen Harbor Blvd.
Glendale, AZ 85307

Visit us on the web at www.conair.com

©2021 Conair LLC
Glendale, AZ 85307

SKIN1
21PS075316

IB-16997

GET TO KNOW YOUR SKINCARE FRIDGE

1. Your skincare fridge works best for storing moisturizers, oils, cleansers, face masks, eye masks, facial rollers, makeup products, fragrances, and nail polish.
2. 41°F-54°F is the optimum temperature to store products with antioxidants and natural products lacking preservatives.
3. Keeping products cool can provide skin with soothing anti-inflammatory benefits.
4. Shelf is removable to organize and accommodate any beauty product.

17. The inner temperature might be less than 32° if the ambient temperature is too low. Avoid storing your skincare liquids in the skincare refrigerator if the internal temperature is near 32°F (0°C) or they may freeze.

SAVE THESE INSTRUCTIONS

INSTRUCTIONS FOR USING YOUR SKINCARE FRIDGE

1. Before use, make sure the switch is at "0" position and then plug in your skincare cooler using the attached power cord.
 2. Place your skincare fridge on a flat sturdy surface before plugging in.
 3. Before use, make sure to plug in your skincare fridge using the power cord.
 4. Keep your skincare fridge out of direct sunlight to ensure it works at the optimum temperature.
 5. The temperature of your skincare fridge while cooling products is 41°F-54°F. This helps skincare and makeup products stay chilled and fresh longer, increasing the shelf life of the products.
 6. Place desired products on removable shelf inside skincare fridge and allow the products to cool.
 7. Once products have cooled to the temperature of the fridge, they are ready to be used.
 8. Please note that condensation inside the skincare fridge is normal.
4. If the SUPPLY CORD is damaged, it must be replaced by a special cord from Conair service agent.
 5. Do not use electrical appliances inside the storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
 6. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
 7. Children should be supervised to ensure that they do not play with the appliance.
 8. **Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service center for examination and repair.**
 9. Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
 10. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
 11. Never drop or insert any object into any opening or hose.
 12. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
 13. Make sure the skincare fridge is always plugged in to ensure the products are stored at a cool temperature.
 14. The skincare fridge is not a refrigerator. Do not use for freezing fresh meat, foods and drinks.
 15. Please do not open the door frequently. The door should not be opened for long periods of time in order to keep better cooling performance.
 16. If the skincare fridge will not be used for an extended period of time, unplug it immediately.

ADDITIONAL PARTS



1. Includes 1 removable shelf for organizing and storing your products.
2. Includes 1 storage bin on the door for holding your skincare products and beauty tools.



CLEANING AND MAINTENANCE INSTRUCTIONS

- Unplug your beauty fridge before cleaning.
- Wipe the outside of the fridge with a clean cloth.
- Wash removable shelf and bin as well as the inside walls with warm soapy water and dry thoroughly. (Shelf is NOT dishwasher safe.)
- Do not immerse your beauty fridge or power cord in water.

CAUTION

Never allow the power supply cord to be pulled, twisted or severely bent. Never wrap the cord tightly around the unit. Damage will occur at the high flex point of entry into the unit, causing it to rupture and short circuit. Inspect the cord frequently for damage. **Stop use immediately if damage is visible or unit stops or operates intermittently.**

If cord or unit is damaged or does not operate properly, return it for repair to an authorized Conair Service Representative only. No repairs should be attempted by the consumer.

The Beauty Skincare Fridge is for household use only.

STORAGE – Important

When not in use, your unit should be disconnected and stored in a safe, dry location, out of reach of children. Do not wrap line cord around unit. Allow the cord to hang or lie loose and straight at the point of entry into the unit.

the beauty skincare fridge

Model SKIN1

INSTRUCTION GUIDE

CONAIR

GARANTÍA LIMITADA DE UN AÑO (válida en los EE.UU. solamente)

Conair reparará o reemplazará (a su opción) este producto sin cargo por un período de 12 meses a partir de la fecha de compra si presenta defectos de fabricación o materiales.

Para obtener servicio técnico bajo esta garantía, devuelva el producto defectuoso al Centro de Servicio indicado a continuación, junto con su recibo de compra. Los residentes de California solo necesitan dar una prueba de compra y deben llamar al 1-800-3-CONAIR para recibir instrucciones de envío. En ausencia del recibo de compra, el período de garantía será de 12 meses a partir de la fecha de fabricación.

CUALQUIER GARANTÍA, OBLIGACIÓN O RESPONSABILIDAD IMPLÍCITAS, INCLUYENDO, PERO NO LIMITADAS A LA GARANTÍA IMPLÍCITA DE COMERCIABILIDAD Y APTITUD PARA UN PROPÓSITO ESPECÍFICO, ESTARÁN LIMITADAS POR LOS 12 MESES DE LA PRESENTE GARANTÍA ESCRITA.

Algunos Estados no permiten limitaciones en la duración de una garantía implícita, de modo que las limitaciones mencionadas pueden no regir para usted.

CONAIR NO SERÁ RESPONSABLE, EN NINGÚN CASO, POR NINGÚN DAÑO ESPECIAL, INCIDENTAL O CONSECUENTE DEBIDO AL INCUMPLIMIENTO DE ESTA O CUALQUIER OTRA GARANTÍA, EXPRESA O IMPLÍCITA.

Algunos Estados no permiten la exclusión o limitación de daños especiales, incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted.

Esta garantía le otorga derechos legales específicos y usted puede tener otros derechos que varían de un Estado a otro.

MEDIDAS DE SEGURIDAD IMPORTANTES

Al usar aparatos eléctricos, especialmente en presencia de niños, siempre se deben tomar precauciones básicas de seguridad, entre ellas las siguientes:

LEA TODAS LAS INSTRUCCIONES ANTES DEL USO MANTÉNGALO ALEJADO DEL AGUA

PELIGRO — Para reducir el riesgo de electrocución:


- No coloque ni guarde este producto donde pueda caerse o ser empujado a una bañera o un lavabo.
- No coloque la unidad ni la deje caer al agua ot o líquido.
- No trate de alcanzar el aparato después de una caída en agua o en otro líquido; desenchúfelo inmediatamente.**

ADVERTENCIA — Para reducir el riesgo de quemaduras, electrocución, incendio o lesiones personales:

- Supervise el uso de este aparato con cuidado cuando sea usado por, en o cerca de niños o personas con ciertas discapacidades.

**ADVERTENCIA:
SI CREE QUE
NO HAY CORRIENTE
CUANDO EL APARATO
ESTÁ APAGADO,
ESTÁ EQUIVOCADO.**

MANTÉNGALO ALEJADO DEL AGUA



Todos sabemos que no se debe mezclar la electricidad y el agua. Pero ¿Sabe usted que un aparato eléctrico permanece en tensión, aunque esté apagado? Si está conectado, hay corriente. Por lo tanto, siempre desenchufe los aparatos eléctricos después del uso.

SIEMPRE DESENCHUFE LOS APARATOS PEQUEÑOS

- Use este producto solo para el uso previsto y como se describe en este manual. Solo use accesorios recomendados por el fabricante. No guarde sustancias explosivas, tales como latas de aerosol que contengan un agente propulsor inflamable, en este aparato.
- Este aparato ha sido diseñado para uso doméstico.
- Si el cable está dañado, debe ser sustituido por un cable especial, por un técnico de Conair.
- No coloque ningún aparato eléctrico dentro del compartimiento de almacenamiento, a menos que sean aparatos recomendados por el fabricante.
- Los niños o las personas que carezcan de la experiencia o de los conocimientos necesarios para manipular el aparato, o aquellas cuyas capacidades físicas, sensoriales o mentales estén limitadas, no deben usar el aparato sin la supervisión o la dirección de una persona responsable por su seguridad.
- No permita que los niños jueguen con este aparato.
- No use este aparato si el cable o el enchufe están dañados, si no funciona correctamente si está dañado, o después de una caída/caída al agua; devuélvalo a un centro de servicio autorizado para su revisión y reparación.**
- Mantenga el cable lejos de las superficies calientes. No enrolle el cable alrededor del aparato.
- Nunca obstruya los orificios de ventilación, ni coloque el aparato sobre una superficie blanda, tal como una cama o un sofá, donde se puedan obstruir. Mantenga los orificios de ventilación libres de pelusas, cabellos y elementos similares.
- Nunca deje caer ni inserte ningún objeto en ninguna de las aberturas.

AVISO DE LA COMISIÓN FEDERAL DE COMUNICACIONES (FCC)

ADVERTENCIA: Se advierte que las modificaciones no aprobadas expresamente por la autoridad competente en materia de conformidad podrían rescindir el permiso del usuario para operar el equipo.

Este artefacto cumple con la Sección 15 de la Normativa FCC. Su funcionamiento está sujeto a las dos condiciones siguientes: (1) Este artefacto no debe causar ninguna interferencia perjudicial, y (2) Este artefacto debe aceptar cualquier interferencia recibida, incluso aquellas que puedan causar un funcionamiento no deseado.

NOTA: Este equipo ha sido probado y se ha determinado que cumple con los límites de un dispositivo digital de Clase B, según la Sección 15 de la Normativa FCC. Estos límites están diseñados para proporcionar una protección razonable contra las interferencias perjudiciales en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia (RF) y, si no ha sido instalado o usado conforme a las instrucciones, puede ocasionar interferencias perjudiciales para las comunicaciones por radio. No obstante, no hay garantía de que aquellas interferencias no ocurran en una instalación particular. Si este equipo produce alguna interferencia perjudicial en la recepción de radio o televisión, lo que podrá determinarse encendiendo y apagando el equipo, se recomienda tratar de corregir la interferencia, adoptando una o más de las siguientes medidas:

- Reorientar o reubicar la antena receptora
- Aumentar la distancia entre el equipo y e receptor.
- Conectar el equipo a un circuito distinto al que esté conectado el receptor.
- Consultar con el distribuidor o un técnico especializado en radio/TV.

PRECAUCIÓN: Se advierte que las modificaciones no aprobadas expresamente por la autoridad competente en materia de conformidad podrían rescindir el permiso del usuario para operar el equipo.

DECLARACIÓN DE CONFORMIDAD DEL PROVEEDOR

Marca: CONAIR®

Modelo: SKIN1

Descripción: Refrigerador de cosméticos

Parte responsable: Conair LLC

1 Cummings Point Road Stamford, CT 06902 (203) 351-9000

Normas: Normas de la FCC, Sección 15, subsección B, ANSI C63.4-2014

Este artefacto cumple con la Sección 15 de la Normativa FCC.

Su funcionamiento está sujeto a las dos condiciones siguientes:

(1) Este artefacto no debe causar ninguna interferencia perjudicial,

y (2) Este artefacto debe aceptar cualquier interferencia

recibida, incluso aquellas que puedan causar un funcionamiento no deseado.

FECHA DE PUBLICACIÓN: DD/MM/YYYY

Debido a las mejoras continuas en nuestros productos, el producto comprado puede diferir ligeramente del producto ilustrado.

- Coloque el aparato sobre una superficie plana y segura antes de enchufarlo.
- Antes del uso, compruebe que el aparato está enchufado.
- Mantenga el refrigerador de cosméticos lejos de la luz directa del sol para garantizar que funcione a la temperatura óptima.
- La temperatura de refrigeración ideal para los cosméticos y otros productos de cuidado de la piel es entre 41 °F (5 °C) y 54 °F (12 °C). Esto ayuda a que los productos se mantengan frescos por más tiempo, aumentando su vida útil.
- Coloque los productos deseados en el estante removible en el refrigerador y deje que se enfrien.
- Cuando los productos alcancen la temperatura del refrigerador, están listos para su uso.
- Es normal que se forme condensación en el refrigerador.

FAMILIARÍCESE CON SU REFRIGERADOR DE COSMÉTICOS

- Su refrigerador de cosméticos es perfecto para guardar cremas hidratantes, aceites, limpiadores, máscaras faciales y de ojos, rodillos faciales, productos de maquillaje, perfumes y esmaltes de uñas.
- La temperatura de refrigeración ideal para los productos con antioxidantes y los productos naturales sin conservantes es entre 41 °F (5 °C) y 54 °F (12 °C).
- Mantener los productos frescos puede proporcionar a la piel beneficios antiinflamatorios y calmantes.
- El estante es removible para organizar y hacer caber cualquier producto de belleza.

PIEZAS ADICIONALES



- Incluye un estante removible para organizar y almacenar sus productos de belleza.
- Cuenta con un compartimento en la puerta para guardar los productos de cuidado de la piel y los instrumentos de belleza.



refrigerador de cosméticos

Modelo SKIN1

MANUAL DE INSTRUCCIONES

CONAIR

Para su seguridad y para disfrutar plenamente de este producto, siempre lea atentamente las instrucciones antes del uso.

LIMPIEZA Y MANTENIMIENTO INSTRUCCIONES

- Desenchufe el aparato antes de limpiarlo
- Limpie el exterior del aparato con un paño limpio.
- Lave el estante removible, el compartimiento y las paredes internas con agua jabonosa tibia y seque con cuidado todas las piezas. Nota: El estante no es apto para lavavajillas.
- No sumerja el aparato ni el cable en agua.

PRECAUCIÓN

Nunca jale, retuerza ni doble mucho el cable. Nunca lo enrolle con fuerza alrededor del aparato; esto puede dañar la junta flexible que lo conecta al aparato, produciendo su rotura o un cortocircuito. Revise el cable con frecuencia para comprobar que no está dañado. **Deje de usar la unidad inmediatamente si el cable está visiblemente dañado, o si la unidad deja de funcionar, o funciona de manera intermitente.**

Si el cable o el producto están dañados o si el producto no funciona correctamente, devuélvalo a un centro de servicio autorizado. No trate de repararlo. Para uso doméstico solamente.

ALMACENAMIENTO — Importante

Cuando no esté en uso, desenchufe la unidad, permita que se enfríe y guárdela en un lugar seco y seguro, fuera del alcance de los niños. No enrolle el cable alrededor de la unidad. Permita que el cable cuelgue, o que la junta que lo conecta a la unidad esté suelta y recta.