

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be taken, including the following:

### READ ALL INSTRUCTIONS BEFORE USING

### KEEP AWAY FROM WATER

**DANGER** — Any appliance is electrically live even when the switch is off. To reduce the risk of death by electric shock:

1. Always unplug appliance immediately after using.
2. Do not use while bathing or in the shower.
3. Do not place or store appliance where it can fall or be pulled into a tub or sink.
4. Do not place in, or drop into water or other liquids.
5. If an appliance falls into water, unplug it immediately. Do not reach into the water.

**WARNING** — To reduce the risk of burns, electrocution, fire, or injury to persons:

1. This appliance should never be left unattended when plugged in.
2. Do not pull, twist, or wrap line cord around appliance.
3. This appliance should not be used by, or near children or individuals with certain disabilities.

4. Use this appliance only for its intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.

5. Never operate this appliance if it has a damaged cord or plug, if it is not working properly or if it has been dropped or damaged, or dropped into water. Return the appliance to an Authorized Service Center for examination and repair.

6. Keep the cord away from heated surfaces.

7. Never use while sleeping.

8. Never drop or insert any object into any opening or hose.

9. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.

10. Unit is hot when in use. Do not let heated surface touch eyes or skin.

11. Do not place the heated unit directly on any surface while it is hot or plugged in.

**CHECK ALCI SAFETY FEATURE EVERY TIME YOU USE APPLIANCE. WHEN THE LED LIGHT IS FLASHING, THIS INDICATES THE ALCI IS NOT FUNCTIONING PROPERLY. IF THIS IS THE CASE, STOP USING AND RETURN APPLIANCE TO SERVICE CENTER.**

This appliance is equipped with an auto-monitoring function Appliance Leakage Circuit Interrupter (ALCI), a safety feature that renders it inoperable under some abnormal conditions, such as immersion in water. To make sure the ALCI is functioning properly, perform the following test. The purpose of this test is to allow you to make sure the water sensing system (ALCI) is working.

12. Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of hair, lint and other debris.

13. Do not use an extension cord with this appliance.


14. Do not touch hot surfaces of the appliance. Use handles or knobs.

15. Do not attempt to touch the housing of your appliance near the plates, as it is hot when in use.

16. This appliance is not a toy. Keep away from children.

17. Do not use with a voltage converter.

## SAVE THESE INSTRUCTIONS OPERATING INSTRUCTIONS



1. Plug in the appliance and press test button on plug (see diagram).
2. The appliance will stop working. There will be an audible click, reset button will

pop out and the LED light is off. This indicates the ALCI is functioning properly.

3. To reset ALCI with a reset button (see diagram), unit should be unplugged. Then push reset button in and reinsert plug into outlet.

4. If ALCI is not functioning properly and LED light is flashing, stop using immediately and return appliance to service center. If the appliance stops working and the LED light on the ALCI is flashing, return appliance to service center.

5. It is important that if immersion occurs, this unit be brought to a service center. Do not try to reset.

6. Be sure to repeat test every time you use the unit to confirm ALCI is operational.

Should the appliance go off and the reset button pop up during use, this could indicate a malfunction in the unit. Remove plug from outlet and allow the appliance to cool. Reinsert plug into outlet. The appliance should then function normally. If not, return it to an authorized Conair Service Center for evaluation and repair.

The Instant Heat technology has 3 heat settings. There is a temperature range that's gentle and safe for every type of hair, from the finest to the most resistant, and helps you create the look you want. If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-style hair, keep the heat setting on high. Always test a small section of hair to ensure the proper heat setting for your hair. You can vary the iron's temperature according to your particular need!

## STYLING WITH THE QUARTZ CERAMIC-COATED, EASY-GLIDE PLATES & BARREL

Your new styler has a quartz ceramic-coated, easy-glide surface. This means it's not only simpler to clean off styling product residue, etc., after each use, but you'll find that hair glides easily over the surface of the plates as you're styling. The ceramic surface also helps smooth down flyaways. It evenly distributes heat so that the style you create has a salon-perfect, silky smooth, shiny finish.

### UNIQUE AIRFLOW SYSTEM

This styling iron features a unique cooling system for the outer barrel. A fan releases cool air along the outside of the barrel to help set your style and creates long-lasting curls.

### USING INSTANT HEAT, THE 3 HEAT SETTINGS & UNIFORM HEAT RECOVERY SYSTEM

This styling iron features a heater that maintains constant temperature during use for precision styling.


The Instant Heat technology has 3 heat settings. There is a temperature range that's gentle and safe for every type of hair, from the finest to the most resistant, and helps you create the look you want.

If you have fine hair, a low temperature will provide the best results. If you have thick, wavy or hard-to-style hair, keep the heat setting on high. Always test a small section of hair to ensure the proper heat setting for your hair. You can vary the iron's temperature according to your particular need!

## TEMPERATURE SETTING GUIDE

| HAIR TYPE                         | TEMP. CONTROL                      |
|-----------------------------------|------------------------------------|
| FRAGILE/FINE HAIR                 | Low(L) – 320°F                     |
| MEDIUM/NORMAL HAIR                | Medium(M) – 356°F                  |
| WAVY/CURLY HAIR/COARSE/THICK HAIR | High(H) – 400°F                    |
| OUTER BARREL                      | Stays cool with air flow system on |

## GET TO KNOW YOUR STYLER



## GETTING STARTED

Plug the styler into any standard electrical outlet. The RED temperature setting and GREEN fan LED light up immediately. The lights blink and cycle through 3 times and then turn off.

Press and hold ON/OFF button for 1–2 seconds to turn the styler on. The unit will automatically default to the MEDIUM heat setting. The LOW and MEDIUM settings turn to a red LED.

The LOW red LED will remain solid, while the MEDIUM red LED blinks. It will stop blinking and become solid when desired temperature is reached. The GREEN fan LED blinks and then becomes solid. The fan starts to release cool air and will become a solid GREEN when the correct heat setting has been reached.

To select your temperature, press the ON/OFF button again. Press and release button until you reach the temperature you desire. As the temperature increases to the next setting, the LED lights will blink as follows:

● ○ ○

Temperature setting is set to LOW. The LOW red LED blinks, then turns solid when the temperature has been reached.

● ● ○

Temperature setting is set to MEDIUM. The LOW red LED remains solid. MEDIUM red LED light blinks, then turns solid when the temperature has been reached.

● ● ●

Temperature setting is set to HIGH. The LOW and MEDIUM red LED remain solid. HIGH setting light blinks, then turns solid when the temperature has been reached.

● ● ● ●

Temperature setting is set to HIGH. The LOW and MEDIUM red LED remain solid. HIGH setting light blinks, then turns solid when the temperature has been reached.

6. Repeat for each section of hair.

Hair should be clean and completely dry before using the styler. Ensure hair is dry and combed through.

1. Separate a section of hair. The smaller the section, the more defined the curl. The larger the section, the looser the curl or wave.

(Fig.1)



(Fig.2)



(Fig.3)



4. Slowly glide the styler along the length of hair from roots to ends in a downward motion (Fig. 3).

5. Release the hair from the styler. The cool air channels set the style.

6. Repeat for each section of hair.

**INFINITI PRO BY CONAIR**



## INSTRUCTIONS AND STYLING GUIDE

For your safety and continued enjoyment of this product, always read the instruction book carefully before using.



This message about...

**G  
F  
C  
I**  
ROUND  
FAULT  
CIRCUIT  
INTERRUPTERS

...can save a life!

### IF YOU MUST USE YOUR STYLER IN THE BATHROOM, INSTALL A GFCI<sup>®</sup> NOW!

Your local electrician can help you decide which type is best for you – a portable unit that plugs into the electrical outlet or a permanent unit installed by your electrician. The National Electrical Code now requires GFCIs in the bathrooms, garages, and outdoor outlets of all new homes.

### WHY DO YOU NEED A GFCI?

Electricity and water don't mix. If your styler falls into water while it's plugged in, the electric shock can kill you...even if the switch is off. A regular fuse or circuit breaker won't protect you under these circumstances. A GFCI offers you far greater protection.

### A GFCI can save your life! Compared to that, the price is small! Don't wait...install one now!

\*A GFCI is a sensitive device that reacts immediately to a small electric current leak by stopping the electricity flow.

### FEDERAL COMMUNICATIONS COMMISSION NOTICE

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### SUPPLIER'S DECLARATION OF CONFORMITY

**Brand:** InfinitiPRO by Conair

**Model No.:** CD2112

**Description:** Cool Air Curler

**Responsible Party:** Conair Corporation, 1 Cummings Point Road, Stamford, CT 06902 (203) 351-9000

**Standards:** FCC Part 15 Subpart B, ANSI C63.4-2014

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference,

and (2) This device must accept any interference received,

including interference that may cause undesirable operation.

**DATE OF ISSUE:** 06/09/2021

### USER MAINTENANCE

Your styling iron is virtually maintenance free. No lubrication is needed. Keep all vents and openings clear of dirt and dust. If cleaning becomes necessary, disconnect the unit from the power source, allow to cool and wipe exterior with a cloth. If any abnormal condition occurs, unplug the unit, allow it to cool, and return it for repair to an Authorized Service Center only. No repairs should be attempted by the consumer.

### CAUTION

NEVER allow the power supply cord to be pulled, twisted, or severely bent. Never wrap the cord tightly around the appliance. Damage will occur at the high flex point of entry into the appliance, causing it to rupture and short circuit. Inspect the cord frequently for damage. Stop use immediately if damage is visible or if unit stops or operates intermittently.

### STORAGE

When not in use, your appliance is easy to store. Allow appliance to cool, then simply store out of reach of children in a safe, dry location. Do not jerk or strain cord at plug connections. Do not wrap the line cord around the appliance. Allow the cord to hang or lie loose and straight at the point of entry into the appliance.

### ALWAYS UNPLUG SMALL APPLIANCES

### LIMITED ONE-YEAR WARRANTY (U.S. AND CANADA ONLY)

Conair will repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the appliance is defective in workmanship or materials.

To obtain service under this warranty, return the defective product to the service center listed, together with your purchase receipt. California residents need only provide proof of purchase and should call 1-800-3-CONAIR for shipping instructions. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture.

**ANY IMPLIED WARRANTIES, OBLIGATIONS, OR LIABILITIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED IN DURATION TO THE 12-MONTH DURATION OF THIS WRITTEN, LIMITED WARRANTY.** Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

**IN NO EVENT SHALL CONAIR BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER.** Some states do not allow the exclusion or limitation of special, incidental, or consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

### BEAUTY TIPS

To achieve the looks you love and for more great InfinitiPRO by Conair products, visit [infinity.conair.com](http://infiniti.conair.com)

### INSTRUCTIONS AND STYLING GUIDE

Please register this product at [www.conair.com/registration](http://www.conair.com/registration)

For info on any Conair or InfinitiPRO by Conair product, call 1-800-3-CONAIR or visit us on the web at [www.conair.com/infinity](http://www.conair.com/infinity)

# MEDIDAS DE SEGURIDAD IMPORTANTES

Al usar aparatos eléctricos, especialmente en presencia de niños, siempre se deben tomar precauciones básicas de seguridad, entre ellas las siguientes:

## LEA TODAS LAS INSTRUCCIONES ANTES DEL USO

### MANTÉNGALO ALEJADO DEL AGUA

**PELIGRO** — Cualquier aparato enchufado permanece en tensión, aunque esté apagado. Para reducir el riesgo de electrocución:

1. Siempre desenchufe el aparato inmediatamente después del uso.
2. No la use en el baño o la ducha.
3. No coloque ni guarde el aparato donde pue caerse o ser empujado a una bañera o un lavabo.
4. No coloque la unidad ni la deje caer al agua otro líquido.
5. Si el aparato se cae al agua, desenchúfelo inmediatamente; **no trate de alcanzar la unidad en el agua.**



Este mensaje sobre los...

**GFCI** ROUND  
CIRCUIT  
INTERRUPTERS  
(Interruptores de circuito de falla a tierra)

...puede salvar una vida.

**ADVERTENCIA** — Para reducir el riesgo de quemaduras, electrocución, incendio o lesiones personales

1. Nunca descuide/deje el aparato sin vigilancia mientras está conectado.
2. No jale, retuerza ni enrolle el cable alrededor del aparato.
3. Este aparato no debe ser usado po en o cerca de niños o personas con ciertas discapacidades.
4. Use este producto solo para el uso previs y como se describe en este manual. Solo use accesorios recomendados por el fabricante.
5. **No use este aparato si el cable o el enchufe están dañados, si no funciona correctamente, si está dañado, o después de una caída/caída al agua; devuélvalo a un centro de servicio autorizado para su revisión y reparación.**
6. Mantenga el cable lejos de las superfici calientes.
7. Nunca lo use mientras duerm
8. Nunca deje caer ni inserte ningún objeto ninguna de las aberturas.
9. No use el aparato en exteriores, ni lo ha funcionar donde se estén usando productos en aerosol (spray) o donde se esté administrando oxígeno.
10. Este aparato se pone muy caliente dura el uso; mantenga los ojos y la piel alejados de las superficies calientes.
11. **No coloque el aparato sobre ninguna superficie mientras está caliente o enchufado.**
12. Nunca obstruya los orificios de ventilaci ni coloque el aparato sobre una superficie

### ¡SI DEBE USAR EL APARATO EN EL CUARTO DE BAÑO, INSTALE UN INTERRUPTOR DE CIRCUITO DE FALLA A TIERRA\* AHORA!

Su electricista puede ayudar a decidir cuál sistema escoger: un sistema removible que se conecta a la toma de corriente o un sistema permanente que él instalará. El Código Nacional de Electricidad ahora exige que todos los enchufes ubicados en los cuartos de baño, los garajes y las partes exteriores de las casas nuevas sean equipados con un interruptor de circuito de falla a tierra (GFCI, por sus siglas en inglés).

**¿POR QUÉ NECESA UN INTERRUPTOR DE CIRCUITO DE FALLA A TIERRA?** La electricidad y el agua no deben juntarse. Si el aparato se cae al agua mientras está conectado, una descarga eléctrica puede causarle a usted la muerte... **aunque el interruptor esté en la posición de apagado.** Un fusible o un disyuntor/interruptor de circuito regular no lo protegerán en esta situación. Un interruptor de falla a tierra ofrece más protección.

**¡Un interruptor de circuito de falla a tierra puede salvar su vida! ¡Comparado con ella, el precio es bajo! ¡No espere...instale uno ahora mismo!**

\*Un interruptor de circuito de falla a tierra (GFCI, por sus siglas en inglés) es un dispositivo sensible que reacciona inmediatamente a una pequeña pérdida de corriente, deteniendo el flujo de electricidad.

- Reorientar o reubicar la antena receptora.
- Aumentar la distancia entre el equipo y el receptor.
- Conectar el equipo a un circuito distinto al que esté conectado el receptor.

blanda, tal como una cama o un sofá, donde se puedan obstruir. Mantenga los orificios de ventilación libres de pelusas, cabellos y elementos similares.

13. No use un cable alargador/de extensión con este aparato.
14. No toque las superficies calientes; use mangos/asas/agarraderas y los botones/perillas.
15. La carcasa del aparato cerca de las pla se pone muy caliente durante el uso; no la toque.
16. Este aparato no es un juguete; manténg fuera del alcance de los niños.
17. No use este aparato con un converti de voltaje.

## GUARDE ESTAS INSTRUCCIONES INSTRUCCIONES DE OPERACIÓN

Para uso doméstico solamente. Úselo solamente con corriente alterna (60 Hz). Este aparato ha sido diseñado para funcionar con corriente de 120 V AC.

El cable de este aparato cuenta con un enchufe polarizado (una pata es más ancha que la otra). Como medida de seguridad, se podrá encubar de una sola manera en la toma de corriente polarizada. Si no entra en la toma de corriente, invierta. Si aun así no entra completamente, comuníquese con un electricista. No intente modificar esta función de seguridad.

**NOTA: No use este aparato en cable sintético/extensiones.**

### AVISO DE LA COMISIÓN FEDERAL DE COMUNICACIONES (FCC)

**ADVERTENCIA:** Se advierte que las modificaciones no aprobadas expresamente por la autoridad competente en materia de conformidad podrían rescindir el permiso del usuario para operar el equipo.

Este artefacto cumple con la Sección 15 de la Normativa FCC. Su funcionamiento está sujeto a las dos condiciones siguientes: (1) Este artefacto no debe causar ninguna interferencia perjudicial, y (2) Este artefacto debe aceptar cualquier interferencia recibida, incluso aquellas que puedan causar un funcionamiento no deseado.

**NOTA:** Este equipo ha sido probado y se ha determinado que cumple con los límites de un dispositivo digital de Clase B, según la Sección 15 de la Normativa FCC. Estos límites están diseñados para proporcionar una protección razonable contra las interferencias perjudiciales en una instalación residencial. Este equipo genera, usa y puede irradiar energía de radiofrecuencia (RF) y, si no ha sido instalado o usado conforme a las instrucciones, puede ocasionar interferencias perjudiciales para las comunicaciones por radio. No obstante, no hay garantía de que aquellas interferencias no ocurran en una instalación particular. Si este equipo produce alguna interferencia perjudicial en la recepción de radio o televisión, lo que podrá determinarse encendiendo y apagando el equipo, se recomienda tratar de corregir la interferencia, adoptando una o más de las siguientes medidas:

- Reorientar o reubicar la antena receptora.
- Aumentar la distancia entre el equipo y el receptor.
- Conectar el equipo a un circuito distinto al que esté conectado el receptor.

### FUNCIÓN DE AUTOCONTROL INTERRUPTOR DE CONTROL DE POTENCIA CON INDICADOR LED

**PRUEBE EL INTERRUPTOR DE CONTROL DE POTENCIA ANTES DE CADA USO. CUANDO EL INDICADOR LUMINOSO PARPADEA, ESTO SIGNIFICA QUE EL INTERRUPTOR DE CONTROL DE POTENCIA NO FUNCIONA CORRECTAMENTE. DEJE DE USAR EL APARATO INMEDIATAMENTE Y DEVUÉVALO A UN CENTRO DE SERVICIO AUTORIZADO.**

Este aparato cuenta con un interruptor de control de potencia ("ALCI", por sus siglas en inglés) que apaga el aparato inmediatamente si este cae al agua. Haga la prueba siguiente antes de cada uso para comprobar que el interruptor de control de potencia y el sistema de detección de agua funcionan correctamente:



1. Enchufe el apar y apriete el botón de prueba (véase el gráfico).
2. El aparato dejará funcionar. Escuchará un "clic", el botón de reinicio saltará y el indicador luminoso se mantendrá apagado.

Si el indicador luminoso se mantiene apagado, esto significa que el interruptor de control de potencia está funcionando correctamente.

3. Para reiniciarlo, desenchufe el apar. Luego, presione el botón de reinicio y vuelva a conectar el cable.
4. Si interruptor de control de potencia funciona correctamente y el indicador luminoso empieza a parpadear, deje de usar el aparato inmediatamente y devuélvalo a un centro de servicio autorizado. Si el aparato deja de funcionar y el indicador luminoso se enciende,

Este aparato cuenta con una potente resistencia que logra un calentamiento muy rápido y mantiene la temperatura constante durante el uso. A diferencia de otras herramientas cuya

Indicadores LED de temperatura

Botón de encendido/apagado

Cable giratorio de 1.85 m

Punta aislante

El exterior del tubo se mantiene frío gracias al sistema de circulación de aire

Placas con revestimiento de cerámica/cuarzo; se calientan hasta 400 °F (205 °C)

Voltaje único

Botón de bloqueo/liberación de las placas

Indicador LED de encendido/apagado del ventilador

Indicadores LED de temperatura

Botón de encendido/apagado

Indicadores LED de temperatura